

User Manual

EFace10

Date: January 2022

Doc Version: 1.0

English

Thank you for choosing our product. Please read the instructions carefully before operation. Follow these instructions to ensure that the product is functioning properly. The images shown in this manual are for illustrative purposes only.



For further details, please visit our Company's website
www.zkteco.com.

Copyright © 2022 ZKTECO CO., LTD. All rights reserved.

Without the prior written consent of ZKTeco, no portion of this manual can be copied or forwarded in any way or form. All parts of this manual belong to ZKTeco and its subsidiaries (hereinafter the "Company" or "ZKTeco").

Trademark

ZKTeco is a registered trademark of ZKTeco. Other trademarks involved in this manual are owned by their respective owners.

Disclaimer

This manual contains information on the operation and maintenance of the ZKTeco equipment. The copyright in all the documents, drawings, etc. in relation to the ZKTeco supplied equipment vests in and is the property of ZKTeco. The contents hereof should not be used or shared by the receiver with any third party without express written permission of ZKTeco.

The contents of this manual must be read as a whole before starting the operation and maintenance of the supplied equipment. If any of the content(s) of the manual seems unclear or incomplete, please contact ZKTeco before starting the operation and maintenance of the said equipment.

It is an essential pre-requisite for the satisfactory operation and maintenance that the operating and maintenance personnel are fully familiar with the design and that the said personnel have received thorough training in operating and maintaining the machine/unit/equipment. It is further essential for the safe operation of the machine/unit/equipment that personnel has read, understood and followed the safety instructions contained in the manual.

In case of any conflict between terms and conditions of this manual and the contract specifications, drawings, instruction sheets or any other contract-related documents, the contract conditions/documents shall prevail. The contract specific conditions/documents shall apply in priority.

ZKTeco offers no warranty, guarantee or representation regarding the completeness of any information contained in this manual or any of the amendments made thereto. ZKTeco does not extend the warranty of any kind, including, without limitation, any warranty of design, merchantability or fitness for a particular purpose.

ZKTeco does not assume responsibility for any errors or omissions in the information or documents which are referenced by or linked to this manual. The entire risk as to the results and performance obtained from using the information is assumed by the user.

ZKTeco in no event shall be liable to the user or any third party for any incidental, consequential, indirect, special, or exemplary damages, including, without limitation, loss of business, loss of profits, business interruption, loss of business information or any pecuniary loss, arising out of, in connection with, or

relating to the use of the information contained in or referenced by this manual, even if ZKTeco has been advised of the possibility of such damages.

This manual and the information contained therein may include technical, other inaccuracies or typographical errors. ZKTeco periodically changes the information herein which will be incorporated into new additions/amendments to the manual. ZKTeco reserves the right to add, delete, amend or modify the information contained in the manual from time to time in the form of circulars, letters, notes, etc. for better operation and safety of the machine/unit/equipment. The said additions or amendments are meant for improvement /better operations of the machine/unit/equipment and such amendments shall not give any right to claim any compensation or damages under any circumstances.

ZKTeco shall in no way be responsible (i) in case the machine/unit/equipment malfunctions due to any non-compliance of the instructions contained in this manual (ii) in case of operation of the machine/unit/equipment beyond the rate limits (iii) in case of operation of the machine and equipment in conditions different from the prescribed conditions of the manual.

The product will be updated from time to time without prior notice. The latest operation procedures and relevant documents are available on <http://www.zkteco.com>.

If there is any issue related to the product, please contact us.

ZKTeco Headquarters

Address ZKTeco Industrial Park, No. 32, Industrial Road,
Tangxia Town, Dongguan, China.

Phone +86 769 - 82109991

Fax +86 755 - 89602394

For business related queries, please write to us at: sales@zkteco.com.

To know more about our global branches, visit www.zkteco.com.

About the Company

ZKTeco is one of the world's largest manufacturer of RFID and Biometric (Fingerprint, Facial, Finger-vein) readers. Product offerings include Access Control readers and panels, Near & Far-range Facial Recognition Cameras, Elevator/floor access controllers, Turnstiles, License Plate Recognition (LPR) gate controllers and Consumer products including battery-operated fingerprint and face-reader Door Locks. Our security solutions are multi-lingual and localized in over 18 different languages. At the ZKTeco state-of-the-art 700,000 square foot ISO9001-certified manufacturing facility, we control manufacturing, product design, component assembly, and logistics/shipping, all under one roof.

The founders of ZKTeco have been determined for independent research and development of biometric verification procedures and the productization of biometric verification SDK, which was initially widely applied in PC security and identity authentication fields. With the continuous enhancement of the development and plenty of market applications, the team has gradually constructed an identity authentication ecosystem and smart security ecosystem, which are based on biometric verification techniques. With years of experience in the industrialization of biometric verifications, ZKTeco was officially established in 2007 and now has been one of the globally leading enterprises in the biometric verification industry owning various patents and being selected as the National High-tech Enterprise for 6 consecutive years. Its products are protected by intellectual property rights.

About the Manual

This manual introduces the operations of **EFace10**.

All figures displayed are for illustration purposes only. Figures in this manual may not be exactly consistent with the actual products.

Features and parameters with ★ are not available in all devices.

Document Conventions

Conventions used in this manual are listed below:

GUI Conventions

For Software	
Convention	Description
Bold font	Used to identify software interface names e.g., OK , Confirm , Cancel .
>	Multi-level menus are separated by these brackets. For example, File > Create > Folder.
For Device	
Convention	Description
< >	Button or key names for devices. For example, press <OK>.
[]	Window names, menu items, data table, and field names are inside square brackets. For example, pop up the [New User] window.
/	Multi-level menus are separated by forwarding slashes. For example, [File/Create/Folder].

Symbols

Convention	Description
	This represents a note that needs to pay more attention to.
	The general information which helps in performing the operations faster.
	The information which is significant.
	Care taken to avoid danger or mistakes.
	The statement or event that warns of something or that serves as a cautionary example.

Table of Contents

SAFETY MEASURES	8
1 INSTRUCTION FOR USE	9
1.1 STANDING POSITION, FACIAL EXPRESSION AND STANDING POSTURE.....	9
1.2 FACE REGISTRATION	10
1.3 STANDBY INTERFACE	11
1.4 VIRTUAL KEYBOARD.....	12
1.5 VERIFICATION MODE	12
1.5.1 FACIAL VERIFICATION	12
1.5.2 CARD VERIFICATION★.....	14
1.5.3 PASSWORD VERIFICATION.....	15
1.5.4 COMBINED VERIFICATION.....	16
2 MAIN MENU	18
3 USER MANAGEMENT.....	20
3.1 USER REGISTRATION	20
3.1.1 USER ID AND NAME	20
3.1.2 USER ROLE	21
3.1.3 DEPARTMENT★	21
3.1.4 FACE.....	22
3.1.5 CARD★	22
3.1.6 PASSWORD.....	22
3.1.7 PROFILE PHOTO	23
3.2 SEARCH USER	23
3.3 EDIT USER.....	24
3.4 DELETE USER.....	24
3.5 DISPLAY STYLE.....	25
4 USER ROLE	26
5 COMMUNICATION SETTINGS.....	27
5.1 ETHERNET SETTINGS	27
5.2 PC CONNECTION	28
5.3 WIRELESS NETWORK★	28
5.4 CLOUD SERVER SETTING.....	30
5.5 NETWORK DIAGNOSIS	31
6 SYSTEM SETTINGS.....	32
6.1 DATE TIME.....	32
6.2 ATTENDANCE.....	33
6.3 FACE PARAMETERS	34
6.4 FACTORY RESET.....	37
6.5 USB UPGRADE.....	37

7	PERSONALIZE SETTINGS	38
7.1	INTERFACE SETTINGS	38
7.2	VOICE SETTINGS	39
7.3	BELL SCHEDULES.....	39
7.4	PUNCH STATES OPTIONS	41
7.5	SHORTCUT KEY MAPPINGS	42
8	DATA MANAGEMENT	44
8.1	DELETE DATA	44
9	DEPARTMENT MANAGEMENT★	46
9.1	ADD A DEPARTMENT	46
9.2	EDIT A DEPARTMENT	47
9.3	DELETE A DEPARTMENT	48
10	SHIFT SET★.....	49
10.1	ATTENDANCE RULE.....	49
10.2	SHIFT SETTING.....	50
10.3	SCHEDULE.....	51
11	REPORT★	54
11.1	DOWNLOAD ATT. REPORT	54
11.2	DOWNLOAD ATT. SETTING REPORT	56
11.3	UPLOAD ATT. SETTING REPORT.....	58
11.4	SETTING	58
12	ACCESS CONTROL.....	59
12.1	ACCESS CONTROL OPTIONS	59
13	USB MANAGER.....	60
13.1	DOWNLOAD	60
13.2	UPLOAD	61
13.3	DOWNLOAD OPTIONS.....	61
14	ATTENDANCE SEARCH	62
15	WORK CODE	63
15.1	ADD A WORK CODE	63
15.2	ALL WORK CODES	64
15.3	WORK CODE OPTIONS	64
16	AUTOTEST	65
17	SYSTEM INFORMATION.....	66
18	CONNECT TO ZKBIOACCESS IVS SOFTWARE	67
18.1	SET THE COMMUNICATION ADDRESS.....	67
18.2	ADD DEVICE ON THE SOFTWARE	67

18.3 ADD PERSONNEL ON THE SOFTWARE	68
APPENDIX 1	69
SELF-SERVICE ATTENDANCE TERMINAL FAQs	69
REQUIREMENTS OF LIVE COLLECTION AND REGISTRATION OF VISIBLE LIGHT FACE IMAGES.....	74
REQUIREMENTS FOR VISIBLE LIGHT DIGITAL FACE IMAGE DATA	75
APPENDIX 2	76
PRIVACY POLICY.....	76
ECO-FRIENDLY OPERATION.....	79

Safety Measures

The below instructions intend to ensure that the user can use the product correctly to avoid danger or property loss. The following precautions are to keep the user's safety and prevent any damage. Please read carefully before installation.

1. **Read, follow, and retain instructions** - All safety and operational instructions must be properly read and followed before bringing the device into service.
2. **Do not ignore warnings** - Adhere to all warnings on the unit and in the operating instructions.
3. **Accessories** - Use only manufacturer-recommended or product-sold accessories. Please do not use any other components other than manufacturer suggested materials.
4. **Precautions for the installation** – Do not place this device on an unstable stand or frame. It may fall and cause serious injury to persons and damage to the device.
5. **Service** - Do not try to service this unit yourself. Opening or removing covers may expose you to hazardous voltages or other hazards.
6. **Damage requiring service** - Disconnect the system from the main AC or DC power source and refer service personnel under the following conditions:
 - When cord or connection control is affected.
 - When any liquid is spilled, or an item dropped into the system.
 - If exposed to water and/or an inclement weather (rain, snow, and more).
 - If the system is not operating normally under operating instructions.Just change controls defined in operating instructions. Improper adjustment of the controls may result in damage and involve a qualified technician to return the device to normal operation.
7. **Replacement parts** - When replacement parts are needed, service technicians must only use replacement parts provided by the supplier. Unauthorized substitutes can result in a burn, shock, or other hazards.
8. **Safety check** - On completion of service or repair work on the unit, ask the service technician to perform safety checks to ensure proper operation of the unit.
9. **Power sources** - Operate the system only from the label's power source form. If the sort of power supply to use is unclear, call your dealer.
10. **Lightning** - External lightning conductors can be installed to protect against electrical storms. It stops power-ups from destroying the system.


NOTE: The devices should be installed in areas with limited access.

1 Instruction for Use

Before getting into the device features and its functions, it is recommended to be familiar to the below fundamentals.


1.1 Standing Position, Facial Expression and Standing Posture

- **The recommended distance**



It is recommended to have a 0.5m space between the device and the user whose height is in a range of 1.55m to 1.85m. Users may slightly move forwards or backward to improve the character recognition of facial images

- **Recommended Standing Posture and Facial Expression**



Standing Posture




Facial Expression

NOTE: During enrolment and verification, please maintain natural facial expression and standing posture.

1.2 Face Registration

Try to keep the face in the centre of the screen during registration. Please face towards the camera and stay still during face registration. The screen should look like this:



Correct face registration and authentication method

● Recommendation for registering a face


- ❖ When registering a face, maintain a distance of 40cm to 80cm between the device and the face.
- ❖ Be careful to keep your facial expression natural and not to change. (smiling, drawn face, wink, etc.)
- ❖ If you do not follow the instructions on the screen, the face registration may take longer or may fail.
- ❖ Be careful not to cover the eyes or eyebrows.
- ❖ Do not wear hats, masks, sunglasses, or eyeglasses.
- ❖ Be careful not to display two faces on the screen. Register one person at a time.
- ❖ It is recommended for a user wearing glasses to register both faces with and without glasses.

● Recommendation for authenticating a face

- ❖ Ensure that the face appears inside the guideline displayed on the screen of the device.
- ❖ Sometimes, authentication may fail due to the change in the wearing glasses then the one used while registration. In such a case, you may require authenticating your face with the previously worn glasses. If your face was registered without glasses, you should authenticate your face without glasses further.
- ❖ If a part of the face is covered with a hat, a mask, an eye patch, or sunglasses, authentication may fail. Do not cover the face, allow the device to recognize both the eyebrows and the face.

1.3 Standby Interface


After connecting the power supply, the following standby interface is displayed:



- Click  to enter the User ID input interface.
- When there is no Super Administrator set in the device, tap  to go to the menu.
- After adding a Super Administrator on the device, it requires the Super Administrator's verification before entering the menu functions.

NOTE: For the security of the device, it is recommended to register super administrator the first time you use the device.

- ★The punch state options can also be displayed and used directly on the standby interface. Tap anywhere on the screen apart from the icons, and six shortcut keys appears on the screen, as shown in the figure below:



- Press the corresponding punch state key to select your current punch state, which is displayed in green.

NOTE: The punch state options are off by default and need to be changed to other option. Refer [7.4 Punch States Options](#) in order to get the punch state options on the standby screen.

1.4 Virtual Keyboard



NOTE:

The device supports the input in Chinese language, English language, numbers, and symbols.


- Click [**En**] to switch to the English keyboard.
- Press [**123**] to switch to the numeric and symbolic keyboard.
- Tap [**ABC**] to return to the alphabetic keyboard.
- Tap the input box, virtual keyboard appears.
- Tap [**ESC**] to exit the virtual keyboard.

1.5 Verification Mode

1.5.1 Facial Verification

● 1:N Facial Verification

In this verification mode, the device compares the collected facial images with all face data registered in the device. The following is the pop-up prompt of a successful comparison result.




● 1:1 Facial Verification


In this verification mode, the device compares the face captured by the camera with the facial template related to the entered user ID. Press  on the main interface and enter the 1:1 facial verification mode and enter the user ID and tap **[OK]**.



If the user has registered password and card in addition to his/her face, and the verification method is set to password/face/card verification, the following screen will appear. Select the  icon to enter the face verification mode.



After successful verification, the prompt box displays **"Successfully verified"**, as shown below:




If the verification is failed, it prompts **"Please adjust your position!"**.

1.5.2 Card Verification★

● 1:N Card Verification

The 1: N Card Verification mode compares the card number in the card induction area with all the card number data registered in the device; The following is the card verification screen.




● 1:1 Card Verification



The 1:1 Card Verification mode compares the card number in the card induction area with the number associated with the employee's User ID registered in the device.

Press  in the main interface to open the 1:1 card verification mode.


Enter the user ID and tap **[OK]**.



If the user has registered password and face in addition to his/her card, and the verification method is set to password/face/card verification, the following screen will appear. Select the  icon to enter the card verification mode.



After successful verification, the prompt box displays **"Successfully verified"**, as shown below:




1.5.3 Password Verification

The device compares the entered password with the registered password by the given User ID.

Click the  button on the main screen to enter the 1:1 password verification mode. Then, input the user ID and press [OK].



If the user has registered face and card in addition to password, and the verification method is set to password/face/card verification, the following screen will appear. Select the  icon to enter password verification mode.




Input the password and press [OK].




Following are the display screen after entering a correct password and a wrong password respectively.

Verification is successful:



Verification is failed:





1.5.4 Combined Verification

For increased security and accessibility, the device offers the option of using multiple forms of verification methods. A total of 9 different verification combinations can be used, as shown below:

Combined Verification Symbol Definition

Symbol	Definition	Explanation
/	or	This method compares the entered verification of a person with the related verification template previously stored to that Personnel ID in the Device.
+	and	This method compares the entered verification of a person with all the verification template previously stored to that Personnel ID in the Device.





Procedure to set for Combined Verification Mode

- Combined verification requires personnel to register all the different verification method. Otherwise, employees will not be able to successfully verify through the combined verification process.
- For instance, when an employee has registered only the face data, but the device verification mode is set as "**Face + Password**", the employee will not be able to complete the verification process successfully.
- This is because the device compares the scanned face template of the person with registered verification template (both the Face and the Password) previously stored to that Personnel ID in the Device.
- But as the employee has registered only the Face but not the Password, the verification will not get completed and the Device displays "**Verification Failed**".

2 Main Menu

Press  on the Standby interface to enter the **Main Menu**, the following screen will be displayed:



Function Description

Menu	Descriptions
User Mgt.	To Add, Edit, View, and Delete basic information of a User.
User Role	To set the permission scope of the custom role and enroller for the users, that is, the rights to operate the system.
COMM.	To set the relevant parameters of Ethernet, PC Connection, Wireless Network★, Cloud Server Setting, and Network Diagnosis.
System	To set the parameters related to the system, including Date Time, Attendance, Face Parameter, Reset to factory and USB Upgrade.
Personalize	To customize settings of User Interface, Voice, Bell Schedules, Punch State Options, and Shortcut Key Mappings settings.
Data Mgt.	To delete all relevant data in the device.
Department★	Establish the organizational structure of the department, including functions like adding, editing, or deleting the department, and scheduling the department, etc.
Shift set★	Set attendance rules and the number of shifts to be used, and schedule employees. The device supports up to 24 shifts.
Report★	Use USB flash drive to download the attendance statistics form to check on the computer or download the attendance settings form to set shifts on the computer, assign shifts to employees and then upload the attendance settings form. At this time, the device will give priority to the use of the schedule of the settings form.
Access Control	To set the parameters of the lock.
USB Manager	To upload or download the specific data by a USB drive.

Attendance Search	To query the specified Attendance Record, check Attendance Photo, and Blocklist ATT Photo.
Work Code	Set different type of work.
Autotest	To automatically test whether each module functions properly, including the LCD Screen, Audio, Camera, and real-time clock.
System Info	To view Data Capacity and Device and Firmware information of the current device.

3 User Management

3.1 User Registration

Click **User Mgt.** on the main menu.



3.1.1 User ID and Name

Tap **New User**. Enter the **User ID** and **Name**.

New User		1↓
User ID		3
Name		
User Role	Normal User	
Department	Company	
Verification Mode	Password/Card/Face	
Face		0

New User		1↓
Department	Company	
Verification Mode	Password/Card/Face	
Face		0
Card Number		
Password		
Profile Photo		0

Notes:

- 1) A name can take up to 36 characters.
- 2) The user ID may contain 1-9 digits by default.
- 3) During the initial registration, you can modify your ID, which can't be modified after registration.
- 4) If a message "**Duplicated!**" pops up, you must choose another ID as the enter User ID already exists.

3.1.2 User Role

On the New User interface, tap **User Role** to set the role for the user as either **Normal User** or **Super Admin**.

- **Super Admin:** The Super Administrator owns all management privileges in the device.
- **Normal User:** If the Super Admin is registered already in the device, then the Normal Users will not have the privilege to manage the system and can only access authentication verifications.
- **User Defined Roles:** The Normal User can also be assigned custom roles with **User Defined Role**. The user can be permitted to access several menu options as required.

User Role	
☒	Normal User
☐	Super Admin

NOTE: If the selected user role is the Super Admin, the user must pass the identity authentication to access the main menu. The authentication is based on the authentication method(s) that the super administrator has registered. Please refer to [1.5 Verification Mode](#).

3.1.3 Department★

There are 8 default departments of the equipment, namely "Company", "Executive Dept.", "Sales", "Financial Dept.", "Production", "Purchasing Dept.", "Custom 1", "Custom 2". Refer to section [9 Department Management](#).


Select the **Department** to enter the department selection interface.

Department	
☒	Company
☐	Executive Dept.
☐	Sales
☐	Financial Dept.
☐	Production
☐	Purchasing Dept.

3.1.4 Face

Tap **Face** in the **New User** interface to enter the face registration page.


- Please face towards the camera and position yourself such that your face image fits inside the white guiding box and stay still during face registration.
- A progress bar shows up while registering the face and a "**Enrolled Successfully**" message is displayed as the progress bar completes.
- If the face is registered already then, the "**Duplicate Face**" message shows up. The registration interface is as follows:



3.1.5 Card★

Tap **Card** in the **New User** interface to enter the card registration page.

- On the Card interface, swipe the card underneath the card reading area. The card registration will be successful.
- If the card is registered already then, the "**Duplicate Card**" message shows up. The registration interface is as follows:



3.1.6 Password

Tap **Password** in the **New User** interface to enter the password registration page.

- On the Password interface, enter the required password and re-enter to confirm it and tap **OK**.

- If the re-entered password is different from the initially entered password, then the device prompts the message as "**Password not match!**", where the user needs to confirm the password again.

NOTE: The password may contain 1 to 8 digits by default.

3.1.7 Profile Photo

Tap on **Profile Photo** in the **New User** interface to go to the Profile Photo registration page.


- When a user registered with a photo authenticates successfully, the registered photo is displayed.
- Tap **Profile Photo** to open the device's camera, then tap the camera icon to take a photo. The captured photo is displayed on the top left corner of the screen and the camera opens up again to take a new photo, after taking the initial photo.

NOTE: While registering a face, the system automatically captures a photo as the profile photo. If you do not register a profile photo, the system automatically sets the photo captured while registration as the default photo.

3.2 Search User


On the **Main Menu**, tap **User Mgt.**, and then tap **All Users** to search for a User.

- On the **All Users** interface, tap on the search bar on the user's list to enter the required retrieval keyword (where the keyword may be the user ID, surname, or full name) and the system will search for the related user information.



3.3 Edit User

On the **All Users** interface, tap on the required user from the list and tap **Edit** to edit the user information.



NOTE: The process of editing the user information is the same as adding a new user, except that the User ID cannot be modified when editing a user. The process in detail refers to [3 User Management](#).

3.4 Delete User

On the **All Users** interface, tap on the required user from the list and tap **Delete** to delete the user or a specific user information from the device. On the **Delete** interface, tap on the required operation and then tap **OK** to confirm the deletion.

Delete Operations

Delete User: Deletes all the user information (deletes the selected User as a whole) from the device.

Delete Face Only: Deletes the face information of the selected user.

Delete Password Only: Deletes the password information of the selected user.

Delete User Photo Only: Deletes the photo of the selected user.




3.5 Display Style


On the **Main Menu**, tap **User Mgt.**, and then tap **Display Style** to enter Display Style setting interface.




All the Display Styles are shown as below:



Single Line Style



Multiple Line Style




Mixed Line Style


4 User Role

User Role facilitates assigning some specific permissions to certain users based on the requirement.



- On the **Main** menu, tap **User Role > User Defined Role** to set the user defined permissions.
- A total of 3 different custom roles can be added. It is the custom operating scope of a user.



- On the **User Defined Role** interface, toggle **Enable Defined Role** to enable or disable the user defined role.
- Tap on **Name** and enter the custom name of the role.




- Then, tap on **Define User Role** and select the required privileges to assign to the new role, and then tap on the **Return** button.
- During privilege assignment, the **Main Menu** function names are displayed on the left and its sub-menus are listed on its right.
- First, tap on the required **Main Menu** function name, and then select its required sub-menus from the list which the user can access.



NOTE: If the User Role is enabled for the device, tap on **User Mgt. > New User > User Role** to assign the created roles to the required users. But if there is no super administrator registered in the device, then the device will prompt "**Please enroll super admin first!**" when enabling the User Role function.

5 Communication Settings

Tap **COMM.** on the **Main Menu** to set the relevant parameters of Ethernet, PC Connection, Wireless Network★, Cloud Server, and Network Diagnosis.



5.1 Ethernet Settings

When the device needs to communicate with a PC over the Ethernet, you need to configure network settings and ensure that the device and the PC are connect to the same network segment.

Tap **Ethernet** on the **Comm.** Settings interface to configure the settings.

	Ethernet	
IP Address	192.168.163.99	
Subnet Mask	255.255.255.0	
Gateway	192.168.163.1	
DNS	0.0.0.0	
TCP COMM.Port	4370	
DHCP	☐	

	Ethernet	
Subnet Mask	255.255.255.0	
Gateway	192.168.163.1	
DNS	0.0.0.0	
TCP COMM.Port	4370	
DHCP	☐	
Display in Status Bar	☒	

Function Description

Function Name	Descriptions
IP Address	The default IP address is 192.168.1.201. It can be modified according to the network availability.
Subnet Mask	The default Subnet Mask is 255.255.255.0. It can be modified according to the network availability.
Gateway	The default Gateway address is 0.0.0.0. It can be modified according to the network availability.
DNS	The default DNS address is 0.0.0.0. It can be modified according to the network availability.

TCP COMM. Port	The default TCP COMM Port value is 4370. It can be modified according to the network availability.
DHCP	It stands for Dynamic Host Configuration Protocol. It dynamically allocates IP addresses for clients via server.
Display in Status Bar	Toggle to set whether to display the network icon on the status bar.

5.2 PC Connection

Comm Key facilitates to improve the security of data by setting the communication between the device and the PC. Once the Comm Key is set, a connection password is required to connect the device to the PC software.

Tap **PC Connection** on the **Comm.** settings interface to configure the communication settings.

PC Connection	
Comm Key	*****
Device ID	1

Function Description

Function Name	Descriptions
Comm Key	The default password is 0 and can be changed later. The Comm Key can contain 1-6 digits.
Device ID	It is the identification number of the device, which ranges between 1 and 254.

5.3 Wireless Network★



The device provides a Wi-Fi module, which can be built-in within the device module or can be externally connected.

The Wi-Fi module enables data transmission via Wi-Fi (Wireless Fidelity) and establishes a wireless network environment. Wi-Fi is enabled by default in the device. If you don't need to use the Wi-Fi network, you can toggle the Wi-Fi to disable the button.

Tap **Wireless Network** on the **Comm.** settings interface to configure the Wi-Fi settings.

Search the WIFI Network

- WIFI is enabled in the device by default. Toggle the  button to enable or disable WIFI.
- Once the Wi-Fi is turned on, the device searches for the available WIFI within the network range.
- Tap on the required Wi-Fi name from the available list and input the correct password in the password interface, and then tap **Connect to WIFI (OK)**.




WIFI Enabled: Tap on the required network from the searched network list.

Tap on the password field to enter the password, and then tap on **Connect to WIFI (OK)**.

- When the WIFI is connected successfully, the initial interface will display the Wi-Fi  logo.

Add WIFI Network Manually

The Wi-Fi can also be added manually if the required Wi-Fi does not show on the list.



Tap on **Add WIFI Network** to add the WIFI manually.

On this interface, enter the WIFI network parameters. (the added network must exist.)

NOTE: After successfully adding the WIFI manually, follow the same process to search for the added WIFI name. Click [here](#) to view the process to search the WIFI network.

Advanced Setting

On the **Wireless Network** interface, tap on **Advanced** to set the relevant parameters as required.

Wireless Network
PLtest-8
testwork-3
pl-3
DIRECT-52FDB298
Add WIFI Network
Advanced

Ethernet
DHCP
IP Address
Subnet Mask
Gateway

Function Description

Function Name	Description
DHCP	Dynamic Host Configuration Protocol (DHCP) dynamically allocates IP addresses to network clients. If the DHCP is enabled, then the IP cannot be set manually.
IP Address	The IP address for the WIFI network, the default is 0.0.0.0. It can be modified according to the network availability.
Subnet Mask	The default Subnet Mask of the WIFI network is 255.255.255.0. It can be modified according to the network availability.
Gateway	The default Gateway address is 0.0.0.0. It can be modified according to the network availability.

5.4 Cloud Server Setting

Tap **Cloud Server Setting** on the **Comm.** settings interface to connect with the ADMS server.

Cloud Server Setting
Server Mode
Enable Domain Name
Server Address
Server Port
Enable Proxy Server
HTTPS

Function Description

Function Name		Description
Enable Domain Name	Server Address	Once this function is turned ON , the domain name mode "http://..." will be used, such as http://www.XYZ.com, while "XYZ" denotes the domain name.
Disable Domain Name	Server Address	The IP address of the ADMS server.
	Server Port	Port used by the ADMS server.
Enable Proxy Server		The IP address and the port number of the proxy server is set manually when the proxy is enabled.
HTTPS		Based on HTTP, transmission encryption and identity authentication ensure the security of the transmission process.

5.5 Network Diagnosis

It helps to set the network diagnosis parameters.

Tap **Network Diagnosis** on the **Comm.** settings interface. Enter the IP address that needs to be diagnosed and tap **Start the diagnostic test** to check whether the network can connect to the device.

Network Diagnosis

IP address diagnostic test


0.0.0.0

Start the diagnostic test

6 System Settings


It helps to set related system parameters to optimize the accessibility of the device.

Tap **System** on the **Main Menu** interface to get to its menu options.



6.1 Date Time

Tap **Date Time** on the **System** interface to set the date and time.



- Tap **Manual Date and Time** to manually set date and time and tap **Confirm** to save.
- Tap **24-Hour Time** to enable or disable this format. If enabled, then select the **Date Format** to set the date format i.e., the way date should be displayed on the device.
- Tap **Daylight Saving Time** to enable or disable the function. If enabled, tap **Daylight Saving Mode** to select a daylight-saving mode and then tap **Daylight Saving Setup** to set the switch time.

Daylight Saving Setup	
Start Month	1
Start Week	1
Start Day	Sunday
Start Time	00:00
End Month	1
End Week	1

Week Mode

Daylight Saving Setup	
Start Date	00-00
Start Time	00:00
End Date	00-00
End Time	00:00

Date Mode

- When restoring the factory settings, the time (24-hour) and date format (YYYY-MM-DD) can be restored, but the device date and time cannot be restored.

NOTE: For example, the user sets the time of the device (18:35 on March 15, 2019) to 18:30 on January 1, 2020. After restoring the factory settings, the time of the equipment will remain 18:30 on January 1, 2020.

6.2 Attendance

Click **Attendance** on the System interface.

	Attendance	
Duplicate Punch Period(m)	1	
Camera Mode	No photo	
Display User Photo	☒	
Attendance Log Alert	99	
Periodic Del of ATT Data	Disabled	
Periodic Del of ATT Photo	99	

	Attendance	
Attendance Log Alert	99	
Periodic Del of ATT Data	Disabled	
Periodic Del of ATT Photo	99	
Periodic Del of Blocklist Photo	Disabled	
Authentication Timeout(s)	3	
Face comparison interval(s)	1	

Function Description

Function Name	Description
Duplicate Punch Period(m)	Within a set time period (unit: minutes), the duplicated attendance record will not be reserved (value ranges from 1 to 999999 minutes).
Camera Mode	Choose whether to capture and save the current snapshot image during verification. There are 5 modes: No Photo: No photo is taken during user verification. Take photo, no save: Photo is taken but not saved during verification. Take photo and save: Photo is taken and saved during verification. Save on successful verification: Photo is taken and saved for each successful verification. Save on failed verification: Photo is taken and saved only for each failed verification.
Display User Photo	Choose whether to display the user photo when the user passes the verification.
Attendance Log Alert	When the record space of the attendance reaches the maximum threshold value, the device automatically displays the memory space warning. Users may disable the function or set a valid value between 1 and 9999.

Periodic Del of ATT Data	When attendance records reach its maximum storage capacity, the device automatically deletes a set of old attendance records. Users may disable the function or set a valid value between 1 and 999.
Periodic Del of ATT Photo	When attendance photos reach its maximum storage capacity, the device automatically deletes a set of old attendance photos. Users may disable the function or set a valid value between 1 and 99.
Periodic Del of Blocklist Photo	When block listed photos reach its maximum storage capacity, the device automatically deletes a set of old block listed photos. Users may disable the function or set a valid value between 1 and 99.
Authentication Timeout(s)	The amount of time taken to display a successful verification message. Valid value: 1~9 seconds.
Face comparison interval (s)	The amount of time required to compare facial templates. Valid value: 0~9 seconds.

6.3 Face Parameters

Tap **Face** on the **System** interface to go to the face parameter settings.

↶	Face	1↴
1:N Threshold Value		47
1:1 Threshold Value		63
Face Enrollment Threshold		70
Face Pitch Angle		30
Face Rotation Angle		25
Image Quality		70

↶	Face	1↴
LED Light Trigger Value		80
Motion Detection Sensitivity		4
Live Detection		☒
Live Detection Threshold		70
Anti-spoofing using NIR		☒
Face Algorithm		

↶	Face	1↴
Minimum Face Size		80
LED Light Trigger Value		80
Motion Detection Sensitivity		4
Live Detection		☒
Live Detection Threshold		70
Anti-spoofing using NIR		☒

Function Description

Function Name	Description
1:N Threshold Value	Under 1:N verification mode, the verification will only be successful when the similarity between the acquired facial image and all registered facial templates is greater than the set value. The valid value ranges from 0 to 100. The higher the thresholds, the lower the misjudgement rate and the higher the rejection rate, and vice versa. It is recommended to set the default value of 47.
1:1 Threshold Value	Under 1:1 verification mode, the verification will only be successful when the similarity between the acquired facial image and the user's facial templates enrolled in the device is greater than the set value. The valid value ranges from 0 to 100. The higher the thresholds, the lower the misjudgement rate and the higher the rejection rate, and vice versa. It is recommended to set the default value of 63.
Face Enrollment Threshold	During face enrollment, 1:N comparison is used to determine whether the user has already registered before. When the similarity between the acquired facial image and all registered facial templates is greater than the set threshold, it indicates that the face has already been registered.
Face Pitch Angle	It is the pitch angle tolerance of a face for facial template registration and comparison. If a face's pitch angle exceeds the set value, it will be filtered by the algorithm, i.e., ignored by the terminal thus no registration and comparison interface will be triggered.
Face Rotation Angle	It is the rotation angle tolerance of a face for facial template registration and comparison. If a face's rotation angle exceeds the set value, it will be filtered by the algorithm, i.e., ignored by the terminal thus no registration and comparison interface will be triggered.
Image Quality	It is the image quality for facial registration and comparison. The higher the value, the clearer image is required.


Minimum Face Size	It sets the minimum face size required for facial registration and comparison. If the minimum size of the captured image is smaller than the set value, then it will be filtered off and not recognized as a face. This value can also be interpreted as the face comparison distance. The farther the individual is, the smaller the face, and the smaller number of pixels of the face obtained by the algorithm. Therefore, adjusting this parameter can adjust the farthest comparison distance of faces. When the value is 0, the face comparison distance is not limited.
LED Light Triggered Value	This value controls the turning on and off of the LED light. The larger the value, the LED light will turn on or off more frequently.
Motion Detection Sensitivity	It sets the value for the amount of change in a camera's field of view known as potential motion detection that wakes up the terminal from standby to the comparison interface. The larger the value, the more sensitive the system would be, i.e., if a larger value is set, the comparison interface activates with much ease, and the motion detection is frequently triggered.
Live Detection	It detects the spoof attempt using visible light images to determine if the provided biometric source sample is of a real person (a live human being) or a false representation.
Live Detection Threshold	It facilitates judging whether the captured visible image is a real person (a live human being). The larger the value, the better the anti-spoofing performance using visible light.
Anti-spoofing using NIR	It uses near-infrared spectra imaging to identify and prevent fake photos and videos attack.
Face Algorithm	It has facial algorithm related information and pause facial template update.

NOTE: Improper adjustment of the exposure and quality parameters may severely affect the performance of the device. Please adjust the exposure parameter only under the guidance of the after-sales service personnel of our company.

6.4 Factory Reset

The Factory Reset function restores the device settings such as communication settings and system settings, to the default factory settings (this function does not clear registered user data).

Tap **Reset** on the **System** interface and then tap **OK** to restore the default factory settings.



6.5 USB Upgrade

With this option, the device firmware can be upgraded by using the upgrade file on a USB disk. Before conducting this operation, ensure that the USB disk is properly inserted into the device and contains the correct upgrade file.

If no USB disk is plugged in, the system gives the following prompt after you tap **USB Upgrade** on the **System** interface.



NOTE: If an upgrade file is required, please contact our technical support. A firmware upgrade is not recommended under normal circumstances.

7 Personalize Settings

Tap **Personalize** on the **Main Menu** interface to customize interface settings, voice, bell, punch state options, and shortcut key mappings.

	Personalize
	User Interface
	Voice
	Bell Schedules
	Punch State Options
	Shortcut Key Mappings

7.1 Interface Settings

Tap **User Interface** on the **Personalize** interface to customize the display style of the main interface.

	User Interface	
Wallpaper		
Language	English	
Menu Screen Timeout(s)	Disabled	
Idle Time to Slide Show(s)	None	
Slide Show Interval(s)	Disabled	
Idle Time to Sleep(m)	Disabled	

	User Interface	
Language	English	
Menu Screen Timeout(s)	Disabled	
Idle Time to Slide Show(s)	None	
Slide Show Interval(s)	Disabled	
Idle Time to Sleep(m)	Disabled	
Main Screen Style	Style 1	


Function Description

Function Name	Description
Wallpaper	It helps to select the main screen wallpaper according to the user preference.
Language	It helps to select the language of the device.
Menu Screen Timeout (s)	When there is no operation, and the time exceeds the set value, the device automatically goes back to the initial interface. The function can either be disabled or set the required value between 60 and 99999 seconds.
Idle Time To Slide Show (s)	When there is no operation, and the time exceeds the set value, a slide show is displayed. The function can be disabled, or you may set the value between 3 and 999 seconds.

Slide Show Interval (s)	It is the time interval in switching between different slide show pictures. The function can be disabled, or you may set the interval between 3 and 999 seconds.
Idle Time to Sleep (m)	If the sleep mode is activated, and when there is no operation in the device, then the device will enter standby mode. This function can be disabled or set a value within 1-999 minutes.
Main Screen Style	It helps selecting the main screen style according to the user preference.

7.2 Voice Settings

Tap **Voice** on the **Personalize** interface to configure the voice settings.




Function Description

Function Name	Description
Voice Prompt	Toggle to enable or disable the voice prompts during function operations.
Touch Prompt	Toggle to enable or disable the keypad sounds.
Volume	Adjust the volume of the device which can be set between 0-100.

7.3 Bell Schedules

Tap **Bell Schedules** on the **Personalize** interface to configure the Bell settings.



New Bell Schedule

Tap **New Bell Schedule** on the **Bell Schedule** interface to add a new bell schedule.

New Bell Schedule	
Bell Status	☐
Bell Time	
Repeat	Never
Ring Tone	bell01.wav
Internal bell delay(s)	5

Function Description

Function Name	Description
Bell Status	Toggle to enable or disable the bell status.
Bell Time	Once the required time is set, the device will automatically trigger to ring the bell during that time.
Repeat	Set the required number of counts to repeat the scheduled bell.
Ring Tone	Select a ring tone.
Internal bell delay(s)	Set the replay time of the internal bell. Valid values ranges from 1 to 999 seconds.

All Bell Schedules

Once the bell is scheduled, on the **Bell Schedules** interface, tap **All Bell Schedules** to view the newly scheduled bell.

Bell Schedules
New Bell Schedule
All Bell Schedules

All Bell Schedules
05:01 PM 
06:01 PM 
07:02 PM 

Edit the scheduled bell

On the **All Bell Schedules** interface, tap on the required bell schedule, and tap **Edit** to edit the selected bell schedule. The editing method is the same as the operations of adding a new bell schedule.

17:01	
Edit	
Delete	

Edit	
Bell Status	☒
Bell Time	05:01 PM
Repeat	Never
Ring Tone	bell01.wav
Internal bell delay(s)	5

Delete a bell

On the **All Bell Schedules** interface, tap the required bell schedule, and tap **Delete**, and then tap **Yes** to delete the selected bell.

18:01	
Edit	
Delete	

17:01	
Edit	
Delete	
Are you sure to execute?	
Yes	
No	

7.4 Punch States Options

Tap **Punch States Options** on the **Personalize** interface to configure the punch state settings.

Punch State Options	
Punch State Mode	Off

Punch State Mode	
☒ Off	
☐ Manual Mode	
☐ Auto Mode	
☐ Manual and Auto Mode	
☐ Manual Fixed Mode	
☐ Fixed Mode	


Function Description

Function Name	Description
Punch State Mode	Off: It disables the punch state function. And the punch state key set under the Shortcut Key Mappings menu becomes invalid. Manual Mode: Switch the punch state key manually, and the punch state key will disappear after Punch State Timeout. Auto Mode: The punch state key will automatically switch to a specific punch status according to the predefined schedule which can be set in the Shortcut Key Mappings. Manual and Auto Mode: The main interface will display the auto-switch punch state key. However, the users will still be able to select an alternative that is the manual attendance status. After timeout, the manual switching punch state key will become auto-switch punch state key. Manual Fixed Mode: After the punch state key is set manually to a particular punch status, the function will remain unchanged until being manually switched again. Fixed Mode: Only the manually fixed punch state key is shown. Users cannot change the status by pressing any other keys.

7.5 Shortcut Key Mappings

Users may define shortcut keys for attendance status and functional keys on the main interface. So, on the main interface, when the shortcut keys are pressed, the corresponding attendance status or the function interface displays directly.

Tap **Shortcut Key Mappings** on the **Personalize** interface to set the required shortcut keys.



Shortcut Key Mappings	
Up Key	Check-In
Down Key	Check-Out
Left Key	Overtime-In
Right Key	Overtime-Out
ESC/[> Key	Break-In
M/OK/[>] Key	Break-Out

- On the **Shortcut Key Mappings** interface, tap on the required shortcut key to configure the shortcut key settings.
- On the **Shortcut Key** (that is "Up Key") interface, tap **function** to set the functional process of the shortcut key either as punch state key or function key.
- If the Shortcut key is defined as a function key (such as New user, All users, etc.), the configuration is done as shown in the image below.

Up Key	
Punch State Value	0
Function	Punch State Options
Name	Check-In


Up Key	
Function	New User

- If the Shortcut key is set as a punch state key (such as check in, check out, etc.), then it is required to set the punch state value (valid value 0~250), name.

NOTE: When the function is set to Undefined, the device will not enable the punch state key.

8 Data Management

On the **Main Menu**, tap **Data Mgt.** to delete the relevant data in the device.



8.1 Delete Data

Tap **Delete Data** on the **Data Mgt.** interface to delete the required data.


Delete Data	1↓
Delete Attendance Data	
Delete Attendance Photo	
Delete Blocklist Photo	
Delete All Data	
Delete Admin Role	
Delete User Photo	

Delete Data	1↓
Delete Blocklist Photo	
Delete All Data	
Delete Admin Role	
Delete User Photo	
Delete Wallpaper	
Delete Screen Savers	

Function Description


Function Name	Description
Delete Attendance Data	To delete attendance records conditionally.
Delete Attendance Photo	To delete attendance photos of designated personnel.
Delete Blocklist Photo	To delete the photos taken during failed verifications.
Delete All Data	To delete information and attendance records of all registered users.
Delete Admin Role	To remove all administrator privileges.
Delete Profile Photo	To delete all profile photos in the device.
Delete Wallpaper	To delete all wallpapers in the device.
Delete Screen Savers	To delete the screen savers in the device.

NOTE: The user may select Delete All or Delete by Time Range when deleting the attendance records, attendance photos, or block listed photos. When selecting Delete by Time Range, you need to set a time range to delete all data within the specified time.



The screenshot shows a menu titled "Delete Attendance Data" with a back arrow icon. It contains two options: "Delete All" and "Delete by Time Range". The "Delete by Time Range" option is highlighted with a light blue background.

Select Delete by Time Range




The screenshot shows a "Start Time" selection screen. At the top, it displays "2021-01-25 00:00". Below this, there are five columns of input fields for Year (YYYY), Month (MM), Day (DD), Hour (HH), and Minute (MM). Each column has up and down arrow buttons. The Year field is currently set to "2021" and is highlighted with a green border. At the bottom, there are two buttons: "Confirm (OK)" and "Cancel (ESC)".

Set the time range and click **OK**.

9 Department Management★


Establishing an organizational structure of the company and arranging departments shift is necessary to view the department information of the device. In this menu option, you can add, edit, or remove a department.

Select **Department** on the main menu interface.




9.1 Add a Department

1. Select **Add Dept.** to enter the Add Dept. interface.



2. Select **Dept. Name** and enter the department name.



3. Select the **Dept. Shifting** of the department.

Dept.Shifting	
☒	Shift 1
☐	Shift 2
☐	Custom 1
☐	Custom 2
☐	Custom 3
☐	Custom 4

Note:

1. The equipment will automatically assign numbers to departments, starting from 1 and so on.
2. **Dept. Shift:** Select the shift attendance used by all users of the department. Shifts can be set in **Shift set > Shifts setting**, with a maximum of 24 shifts set by default. Refer to [Shift Set](#) section.

9.2 Edit a Department

There are 8 departments in the device by default. You can edit the department name and department shift, but you cannot delete them. In addition to the 8 default departments, additional departments can be edited and deleted.

Department Management	
	Add Dept.
	Dept. Lists

1. Select **Dept. Lists** to enter Edit Dept. interface.

Dept. Lists	
1	Company
2	Executive Dept.
3	Sales
4	Financial Dept.
5	Production
6	Purchasing Dept.


2. Select a department to be edit.

Edit Dept.	
Dept. Name	Company
Dept.Shifting	Shift 1


3. Modify the **Dept. Name** and **Dept. Shifting**. (**Note:** The editing of the department is the same as of **Add Dept.**)

9.3 Delete a Department


It helps to remove one or more department as required.



1. Select **Dept. Lists** to enter the Dept. Lists interface.



2. Select a department to delete.




3. Select **Delete**, and then tap **Yes**.

Note: Only departments other than the 8 default departments in the device can be deleted.

10 Shift Set★

Set attendance rules, number of shifts to be used, and schedule employees.


Select **Shift Set** option on the main menu interface.



10.1 Attendance Rule

All attendance statistics are conducted according to the attendance rules. Therefore, the staff attendance rules need to be set first, including late, early leave calculation method, and scheduling type. Once the attendance rules are set, it is not recommended to modify them frequently as it may affect the result of attendance calculation and may cause chaos in the scheduling if it is modified in the middle of the month.

Select **Attendance Rule** on the Shift Set interface.




Item	Descriptions
Count Late On-duty	Set a time after which the lateness calculation for an employee should start. If it is disabled, the lateness calculation starts with the start of working hours.
Count Leave Off-duty	Set a time before which the early leave calculation for an employee should start. If disabled, it is calculated with respect to the end of the working hours.
Schedule Type	The device supports both department and individual-based scheduling. If a company uses one timetable, then only one department needs to be set and department-based scheduling is recommended.


	If the departments have their respective timetables, department-based scheduling is recommended. If employees may take different shifts, individual-based scheduling is recommended.
Default Shift	When individual-based scheduling is used, the default shift applies to all the non-scheduled employees.
SAT On-duty	Enable whether to work normally on Saturdays.
SUN On-duty	Enable whether to work normally on Sundays.

10.2 Shift Setting


Select **Shift Setting** on the Shift Set interface.



1. Select a Shift on the list.



2. Enter the "Shift Name" and set the required start and end times.



Note: The device supports a maximum of 24 shifts including two default shifts (Shift 1 and Shift 2). All the shifts are editable, and a single shift includes three-time ranges at most.

10.3 Schedule


The shifts should be set based on the actual condition of a company. If no shift is set, the system makes attendance calculations based on default shifts set in attendance rules.

Select **Schedule** on the Shift Set interface.



● Department-based Scheduling

Select **Shift Set > Attendance Rule > Schedule Type > Dept. Shifting** to schedule shift for a department.




When a shift is selected for a department, it is implemented for all the members of the department.

● Individual-based Scheduling

Select **Shift Set > Attendance Rule > Schedule Type > Personal Shift** to schedule shift for an individual.

1. Add Schedule

- 1) Tap Shift Set to enter the Schedule interface, and select **Add Personal Shift**.



- 2) Enter an ID. The device automatically displays the name. Select Shift Name.

Add Personal Shift	
User ID	
Name	
Shift Name	Shift 1

2. Edit Schedule

Enter the **Personal Shift Lists** for editing when the scheduling of individual employee needs to be adjusted.

- 1) Select **Personal Shift Lists** on the Personal Shift interface.

Personal Shift	
Add Personal Shift	
Personal Shift Lists	

- 2) Select a scheduled user.

Select Personal Shift	
6 (macabre)	Shift 1
7 (Aymi)	Shift 1

- 3) Select **Edit**, enter and modify the "Shift Name" of the user.


macabre (Shift 1)	
Edit	
Delete	

Note: The User ID cannot be modified. The other operations are the same as those performed to add a shift.


3. Delete a shift

Go to the **Personal Shift Lists**, to delete an employee's schedule that is no longer required.


- 1) Select **Personal Shift Lists** on the Personal Shift interface.



- 2) Select a scheduled user.




- 3) Select **Delete** and click "OK" to delete the Shift successfully.



11 Report★

This menu item allows you to download statistical reports of attendance or attendance setting reports to a USB flash drive or SD card. You can also upload attendance setting reports with defined shifts and employees' schedules. The device gives priority to the schedules in an attendance setting report.


Select **Report** on the main menu interface.




Note: First insert the USB flash drive into the USB slot of the machine, and then enter the main menu to perform the related operations of the **Report**.

11.1 Download Att. Report

1. Select **Download Att. Report** on the Report interface.



2. Set the on-duty time and click **Confirm (OK)**.



3. Set the off-duty time and click **Confirm (OK)**.

Off-duty

2022-01-31

2022 01 31

YYYY MM DD

Confirm (OK) Cancel (ESC)

When Data download succeeds, Press **[M/OK]** to take out the USB disk. The SSRTemplateS.xls gets stored in the USB disk. The Schedule Information, Statistical Report of Attendance, Attendance Record Report, Exception Statistic Report, and Card Report can be viewed on a PC. The following reports show the preceding information:

To make reports more understandable, a report containing two-day attendance records of four employees is provided as an example.

- ❖ **Schedule Information Report:** The report allows you to view schedule records of all employees.

Schedule Information Report																											
Stat.Date: 2020-08-01 ~ 2020-08-15														Special shifts:25-Ask for leave, 26-Out, Null-Holiday													
ID	Name	Department	1	2																							
			FEB	MAR																							
1	Joe	company	1	1																							
2	David	company	1	1																							
3	Mark	company	1	1																							
4	Tom	company	1	1																							

- ❖ **Statistical Report of Attendance:** The report allows you to query the attendance of each person in a specified period. Salaries can be calculated directly based on this report.

Statistical Report of Attendance																						
Stat.Date: 2020-08-01~2020-08-15																						
ID	Name	Department	Work hour		Late		Leave early		Overtime hour		Att. Days (Nor./Real)	Out (Day)	Absen t(Day)	AFL (Day)	Additem payment			Deduction payment			Real pay	Note
			Normal	Real	Times	Min	Times	Min	Workday	Holiday					Label	Overtime	Subsidy	Late/Leave	AFL	Cutpayment		
1	Joe	company	18:00	17:50	0	0	1	10	00:00	00:00	2/2	0	0	0								
2	David	company	18:00	17:48	1	12	0	0	00:00	00:00	2/2	0	0	0								
3	Mark	company	18:00	08:50	1	5	1	10	00:00	00:00	2/2	0	0	0								
4	Tom	company	18:00	18:00	0	0	0	0	00:00	00:00	2/2	0	0	0								

Note: The unit of Work hour and Overtime hour in the Statistical Report of Attendance is HH: MM. For example, 17:50 indicates that the on-duty time is 17 hours and 50 minutes.

- ❖ **Attendance Record Report:** The report lists the daily attendance records of all employees within a specified period.

Attendance Record Report																			
Att. Time 2020-08-01~2020-08-15										Tabulation 2019-08-15									
1	2																		
ID: 1										Name: Joe								Dept.: company	
07:26	07:54																		
12:25	12:56																		
13:31	13:51																		
17:50	18:52																		
ID: 2										Name: David								Dept.: company	
07:36	09:12																		
12:26	15:50																		
13:31	15:51																		
18:31	18:52																		
ID: 3										Name: Mark								Dept.: company	
07:50																			
12:30	09:05																		
17:50																			
ID: 4										Name: Jack								Dept.: company	
07:45	08:11																		
12:50	17:55																		
18:31	18:06																		

- ❖ **Exception Statistic Report:** The report displays the attendance exceptions of all employees within a specified period so that the attendance department handles the exceptions and confirm them with the employees involved and their supervisors.

Exception Statistic Report

Stat. Date: 2020-01-01 ~ 2020-08-15

ID	Name	Department	Date	First time zone		Second time zone		Late time(Min)	Leave early(Min)	Absence (Min)	Total(Min)	Note
				On-duty	Off-duty	On-duty	Off-duty					
1	Joe	company	2019-08-01	07:26	17:50			0	10	0	10	
2	David	company	2019-08-02	09:12	18:52			12	0	0	12	
3	Mark	company	2019-08-01	07:50	17:50			0	10	0	10	
4	Tom	company	2019-08-02	09:05				5	0	535	540	

- ❖ **Card Report:** The report can substitute for clock-based cards and can be sent to each employee for confirmation.

Card Report

Att. Date: 2020-08-01 ~ 2020-08-15

Tabulation: 2020-08-15

company										Joe									
Date 2020-08-01 ~ 2020-08-15										ID 1									
Absen t(Day)	AFL (Day)	Out (Day)	On- duty (Day)	Overtime(H)	Late (Times)	Leave early (Times)				Absen t(Day)	AFL (Day)	Out (Day)	On- duty (Day)	Overtime(H)	Late (Times)	Leave early (Times)			
0	0	0	2	0.0	0.0	0	0	1	10	0	0	0	2	0.0	0.0	1	12	0	0

company										David									
Date 2020-08-01 ~ 2020-08-15										ID 2									
Absen t(Day)	AFL (Day)	Out (Day)	On- duty (Day)	Overtime(H)	Late (Times)	Leave early (Times)				Absen t(Day)	AFL (Day)	Out (Day)	On- duty (Day)	Overtime(H)	Late (Times)	Leave early (Times)			
0	0	0	2	0.0	0.0	1	12	0	0	0	0	0	2	0.0	0.0	1	5	1	10

company										Mark									
Date 2020-08-01 ~ 2020-08-15										ID 3									
Absen t(Day)	AFL (Day)	Out (Day)	On- duty (Day)	Overtime(H)	Late (Times)	Leave early (Times)				Absen t(Day)	AFL (Day)	Out (Day)	On- duty (Day)	Overtime(H)	Late (Times)	Leave early (Times)			
0	0	0	2	0.0	0.0	1	5	1	10	0	0	0	2	0.0	0.0	1	5	1	10

Att. Report

Week Date	First time zone	Second time zone	Overtime
	On-duty	Off-duty	On-duty
	Off-duty	Check-In	Check-Out
01 FEB	07:26	17:50	
02 MAR	07:54	18:52	

Att. Report

Week Date	First time zone	Second time zone	Overtime
	On-duty	Off-duty	On-duty
	Off-duty	Check-In	Check-Out
01 FEB	07:36	18:31	
02 MAR	09:12	18:52	



Att. Report

Week Date	First time zone	Second time zone	Overtime
	On-duty	Off-duty	On-duty
	Off-duty	Check-In	Check-Out
01 FEB	07:50	17:50	
02 MAR	09:05		

11.2 Download Att. Setting Report

If shifts are complex or the shifts of a person are not fixed, it is recommended that the attendance setting report be downloaded and shifts and schedules be set for employees in the attendance setting report.

Select **Download Att. Setting Report** on the Report interface.



Open the setting "AttSettingE.xls" in the USB disk on a PC. Set the Shift in the Attendance setting report. The shifts that have been set on the attendance machine shall be displayed. (For more details, see [Shift Setting](#). You can modify the 24 shifts and add more shifts. After modification, the shifts shall prevail on the attendance machine.

Attendance Setting Report						
Shift						
Number	First time zone		Second time zone		Overtime	
	On-duty	Off-duty	On-duty	Off-duty	Check-In	Check-Out
1	9:00	18:00				
2	9:00	12:00	13:30	18:00		
3	9:00	12:00	13:30	18:00		
4	9:00	12:00	13:30	18:00		
5	9:00	12:00	13:30	18:00		
6	9:00	12:00	13:30	18:00		
7	9:00	12:00	13:30	18:00		
8	9:00	12:00	13:30	18:00		
9	9:00	12:00	13:30	18:00		
10	9:00	12:00	13:30	18:00		
11	9:00	12:00	13:30	18:00		
12	9:00	12:00	13:30	18:00		
13	9:00	12:00	13:30	18:00		
14	9:00	12:00	13:30	18:00		
15	9:00	12:00	13:30	18:00		
16	9:00	12:00	13:30	18:00		
17	9:00	12:00	13:30	18:00		
18	9:00	12:00	13:30	18:00		
19	9:00	12:00	13:30	18:00		
20	9:00	12:00	13:30	18:00		
21	9:00	12:00	13:30	18:00		
22	9:00	12:00	13:30	18:00		
23	9:00	12:00	13:30	18:00		
24	9:00	12:00	13:30	18:00		

i

Enter the On-duty and Off-duty time in the corresponding columns, where the First time zone shall be the On-duty or Off-duty time of Time 1 of [Shift Setting](#), and the Second time zone shall be the On-duty or Off-duty time of Time 2.

For the correct schedule time format, see "What is the correct time format used in the setting reports" in the [Self-Service Attendance Terminal FAQs](#)."

Set a schedule setting report

Enter the **ID**, **Name**, and **Department** respectively on the left of the **Schedule Setting Report**. Set shifts for employees on the right of the **Schedule Setting Report**, where shifts 1–24 are shifts to set the **Attendance Setting Report**. Shift 25 is for leave and Shift 26 is for out.

Schedule Setting Report																																		
Special shifts:25-Ask for leave, 26-Out, Null-Holiday																																		
Schedule date				2020-8-1																														
ID	Name	Department	Card number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
				THU	FRI	SAT	SUN	MON	TUE	WED	THU	FRI	SAT	SUN	MON	TUE	WED	THU	FRI	SAT	SUN	MON	TUE	WED	THU	FRI	SAT	SUN	MON	TUE	WED	THU	FRI	SAT
1	Joe	company																																
2	David	company																																
3	Mark	company																																
4	Jack	company																																


Notes:

- The shifts of only 31 days can be arranged in one schedule setting report. For example, if the scheduling date is 2022-1-1, the schedule setting report contains the schedules of 31 days after 2022-1-1, that is, scheduled from 2022-1-1 to 2022-1-31. If the scheduling date is 2022-1-6, the schedule setting report contains the schedules of 31 days after 2022-1-6, that is, scheduled from 2022-1-6 to 2022-2-5.
- If no schedule setting report is set, all employees use Report 1 by default from Monday to Friday.

11.3 Upload Att. Setting Report

After setting the attendance setting table, save the "Setting Report.xls" to the USB flash drive and reinsert the USB flash drive into the USB slot of the device.

Select **Upload Att. Setting Report** on the Report interface.





After uploading, remove the USB disk or SD card. At this time, the employee information, shift, and department in the setting report can be viewed respectively by the Management User, Shift Number, and Department available in the device. Or the above information and scheduling information can be seen in the standard download report.

Note: If the schedule time format is incorrect, Re-upload the attendance setting report after modification.

11.4 Setting


Set whether to synchronize the card report and distinguish the device ID when downloading the attendance report.

Select **Setting** on the Report interface.




12 Access Control

On the **Main Menu**, tap **Access Control** to set the schedule of lock.



12.1 Access Control Options

Tap **Access Control Options** on the **Access Control** interface to set the parameters of the control lock of the terminal and related equipment.



Function Description

Function Name	Description
Door Lock Delay (s)	The amount of time that the device controls the electric lock to be in unlock state. Valid value: 1~10 seconds; 0 seconds represents disabling the function.
Door Sensor Delay (s)	An alarm is triggered if the door is not closed within a defined time (Door Sensor Delay). The valid value of Door Sensor Delay ranges from 1 to 255 seconds.
Door Sensor Type	There are three Sensor types: None , Normal Open , and Normal Closed . None : It means the door sensor is not in use. Normal Open : The door is always open when electric power is on. Normal Closed : The door is always close when electric power is on.

13 USB Manager

You can import the user information, work code, and attendance data in the device to match the attendance for processing by using a USB disk or import the user information and work code to other fingerprint devices for backup.


NOTE: Before uploading/downloading data from/to the USB disk, insert the USB disk into the USB slot first.

Tap **USB Manager** on the main menu interface.



13.1 Download

Tap **Download** on the **USB Manager** interface.



Function Name	Description
Attendance Data	To download attendance data in a specified time into a USB disk.
User Data	To download all user information from the device into a USB disk.
User Portrait	To download all user photos from the device into a USB disk.
Attendance Photo	To download all attendance photos from the device into a USB disk.
Blocklist Photo	To download all block listed photos (photos taken after failed verifications) from the device into a USB disk.
Work Code	To save the work code in the device to a USB disk.

13.2 Upload

Tap **Upload** on the **USB Manager interface**.

↶	Upload
Screen Saver	
Wallpaper	
User Data	
User Portrait	
Upload work code	

Function Name	Description
Screen Saver	To upload all screen savers from USB disk into the device. You can choose Upload selected photo or Upload all photos . The images will be displayed on the device's main interface once uploaded. Create a folder named "advertise" in the root directory of the USB disk and put the advertising photos in this directory before uploading.
Wallpaper	To upload all wallpapers from USB disk into the device. You can choose Upload selected photo or Upload all photos . The images will be displayed on the screen once uploaded. Create a folder named "wallpaper" in the root directory of the USB disk and put the wallpaper photos in this directory before uploading.
User Date	To upload all the user information from the USB disk into the device.
User Portrait	To upload all user photos from a USB disk into the device.
Upload Work Code	To upload work code from a USB disk into the device.

13.3 Download Options

Tap **Download Options** on the **USB Manager interface**.


↶	Download Options
Encrypt Attendance Data	☒
Delete ATT Data	☒

Function Name	Description
Encrypt Attendance Date	The attendance data is encrypted during the uploading and downloading.
Delete ATT Data	After successful downloading, the attendance data on the device is deleted.

14 Attendance Search

Once the identity of a user is verified, the Attendance Record is saved in the device. This function enables users to check their access records.

Click **Attendance Search** on the **Main Menu** interface to search for the required Attendance Record.



The process of searching for attendance and blocklist photos is similar to that of searching for Attendance Record. The following is an example of searching for Attendance Record.

On the **Attendance Search** interface, tap **Attendance Record** to search for the required record.

1. Enter the user ID to be searched and click **OK**.
For the records of all users, click **OK** without entering any user ID.
2. Select the time range within which the logs need to be searched.

User ID				
Please Input(query all data without input)				
1	2	3		
4	5	6		
7	8	9		
ESC	0	123	OK	

Time Range	
☒	Today
☐	Yesterday
☐	This week
☐	Last week
☐	This month
☐	Last month

3. Once the log search succeeds, tap the record highlighted in green to view its details.
4. The below figure shows the details of the selected record.

Personal Record Search		
Date	User ID	Time
01-25		Number of Records:04
	2	09:58 09:53 09:51 09:48
01-22		Number of Records:09
	1	16:17 16:01 15:57
	2	16:17 16:09 16:02 16:01 15:58 15:57


Personal Record Search					
User ID	Name	Time	Mode	State	
1	Lucy	01-22 16:17	15	255	
1	Lucy	01-22 16:01	15	255	
1	Lucy	01-22 15:57	15	255	

Verification Mode : Face Punch State : 255

15 Work Code

Employees' salaries are subject to their attendance records. An employee can be engaged in more than one type of work which may vary with time. As the pay varies according to the work types, the FFR terminal provides a parameter to indicate the corresponding work type for every attendance record to facilitate rapid understanding of different attendance situations during the handling of attendance data.

On the **Main Menu**, tap **Work Code** to set the work code.



15.1 Add a Work Code

Function Description

Function Name	Description
ID	It is the digital code of the work code. Users may set a valid value between 1 and 99999999.
Name	It is the naming of the work code.

15.2 All Work Codes

You can view, edit and delete work codes in All Work Codes. The process of editing a work code is the same as adding a work code, except that the ID is not allowed to be modified.

All Work Codes	
1	Public
2	OT
3	Developer
4	Design

3
Edit
Delete

15.3 Work Code Options

To set whether entering the work code is a must and whether the entered work code must exist during authentication.

Work Code Options	
Work Code Required	☐
Work Code Must Defined	☐

Work Code Options	
Work Code Required	☒
Input Screen Timeout(s)	5
Work Code Must Defined	☒


In **1: N** or **1:1** verification, the system will automatically pop up the following window. Select the corresponding Word Code manually to verify successfully.

Work Code	
1	Public
2	OT
3	Developer
4	Design
Enter work code	

09:53
 Successfully verified. Name : Mike User ID : 2 Verify : Card

16 Autotest

On the Main Menu, tap Autotest to automatically test whether all modules in the device function properly, including the LCD, Voice, Camera, and Real-Time Clock (RTC).




Function Description

Function Name	Description
Test All	To automatically test whether the LCD, Audio, Camera and RTC are working normally.
Test LCD	To automatically test the display of the LCD screen by displaying all the color bands including pure white and pure black to check whether the screen displays the colors accurately.
Test Voice	To automatically test whether the audio files stored in the device are complete and the voice quality is good.
Test Face	To test if the camera functions properly it checks the photos taken and determines if they are clear enough.
Test Clock RTC	To test the RTC. The device checks whether the clock works normally and accurately with a stopwatch. Touch the screen to start counting and press it again to stop counting.

17 System Information

On the **Main Menu**, tap **System Info** to view the storage status, the version information of the device, and firmware information.



Function Description

Function Name	Description
Device Capacity	Displays the current device's user storage, password, face and card★ storage, administrators, attendance records, attendance and blocklist photos, and profile photos.
Device Info	Displays the device's name, serial number, MAC address, face algorithm, version information, platform information, manufacturer, and manufacture date.
Firmware Info	Displays the firmware version and other version information of the device.

18 Connect to ZKBioAccess IVS Software

18.1 Set the Communication Address

● Device side

1. Tap **COMM.** > **Ethernet** in the main menu to set the IP address and gateway of the device.

(**Note:** The IP address should be able to communicate with the ZKBioAccess IVS server, preferably in the same network segment with the server address)

2. In the main menu, click **COMM.** > **Cloud Server Setting** to set the server address and server port.

Server address: Set the IP address as of ZKBioAccess IVS server.


Server port: Set the server port as of ZKBioAccess IVS(The default is 8881).

Ethernet	
IP Address	192.168.163.99
Subnet Mask	255.255.255.0
Gateway	192.168.163.1
DNS	0.0.0.0
TCP COMM.Port	4370
DHCP	☐

Cloud Server Setting	
Server Mode	ADMS
Enable Domain Name	☐
Server Address	0.0.0.0
Server Port	8081
Enable Proxy Server	☐
HTTPS	☐

● Software side

Login to ZKBioAccess IVS software, click **System** > **Communication** > **Communication Monitor** to set the ADMS service port, as shown in the figure below:



18.2 Add Device on the Software

Add the device by searching. The process is as follows:

1. Click **Attendance** > **Attendance Device** > **Device** > **Search**, to open the Search interface in the software.

2. Click **Search**, and it will prompt [**Searching.....**].
3. After searching, the list and total number of access controllers will be displayed.

Search Device

Search No device found? [Download Search Tools to Local Disk](#)

Total Progress 100% Searched devices count: 1

IP Address Device Type Serial Number

IP Address	MAC Address	Subnet Mask	Gateway Address	Serial Number	Device Type	Set Server	Operations
192.168.213.79	255.255.255.0	192.168.213.1					Add

⚠ The current system communication port is 6609, please make sure the device is set correctly.

Close

4. Click [**Add**] in operation column, a new window will pop-up. Select Icon type, Area, and Add to Level from each dropdown and click [**OK**] to add the device.

18.3 Add Personnel on the Software

1. Click **Personnel > Person > New**:

New

Personnel ID* Department*

First Name Last Name

Gender Mobile Phone

Certificate Type Certificate Number

Birthday Email

Device Verification Card Number

Password

Biological Template

Quantity

 (Optimal Size 120*140).

Access Control | Time Attendance | **Personnel Detail**

Levels Settings
 ☒ General
 [Add](#) [Select All](#) [Unselect All](#)

Superuser
 Device Operation Role
 Disabled ☐
 Set Valid Time ☐

2. Fill in all the required fields and click [**OK**] to register a new user.
3. Click **Attendance > Attendance Device > Device > Control > Synchronize Software Data to the Devices** to synchronize all the data to the device including the new users.

Appendix 1

Self-Service Attendance Terminal FAQs

1. Does self-service attendance terminal support scheduling based on every other day?


A: No.

2. Can the setting records downloaded from the device be edited on WPS software?

A: Yes. Setting records are supported in Microsoft Office 2003, Microsoft Office 2007, and WPS Office 2012 Personal.

3. What is the attendance calculation flow adopted by the self-service attendance terminal?

A: SSR attendance calculation flow.



4. How to calculate special overtime hours?

The following cases are deemed special overtime:

- When an EXCEL schedule record exists and attendance reports are used for attendance calculation, there are check-in and check-out records though there is no schedule (or rest is arranged) for the current date.
- When no EXCEL schedule record is available, there are check-in and check-out records though Saturday and Sunday are non-working days.

Overtime hours refer to the duration counted from the first check-in time to the last check-out time on the current day.

5. How to arrange schedules using the attendance setting report?

Step 1: Insert a USB flash drive into the USB port or SD card into the SD port of the device and download the Attendance Setting Report.xls to the USB flash drive or SD card.

Step 2: Open the Attendance Setting Report.xls on a computer.

Step 3: Set shifts in the Attendance Setting Report.xls as required.

Attendance Setting Report						
Shift						
Number	First time zone		Second time zone		Overtime	
	On-duty	Off-duty	On-duty	Off-duty	Check-In	Check-Out
1	9:00	18:00				
2	9:00	12:00	13:30	18:00		
3	9:00	12:00	13:00	18:00		
4	9:00	12:00	14:00	18:00		

Data enclosed by a red rectangle is new shifts (shift 3 and shift 4). To add a shift, enter a time directly, in the range of 00:00 to 24:00.

Step 4: Arrange schedules for employees.

Schedule Setting Report																																		
Special shifts: 25-Ask for leave, 26-Out, Null-Holiday																																		
Schedule date																																		
ID	Name	Department	Card number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
				SUN	MON	TUE	WED	THU	FRI	SAT	SUN	MON	TUE	WED	THU	FRI	SAT	SUN	MON	TUE	WED	THU	FRI	SAT	SUN	MON	TUE	WED	THU	FRI	SAT	SUN	MON	TUE
1	Joe	company					1	1	1			2	2	2	2	2		2	1	1	1	1			3	3	3	3	3				3	3
3	David	company					2	2	2			1	1	1	1	1		2	3	3	25	3			4	4	4	4	25	4			4	4
3	Mark	company					3	3	3			2	2	2	2	2		2	2	2	2	2			4	4	4	4	26	1			3	3
4	Jack	company										3	3											2		4	4	4						

Date

Schedule Setting Report

Special shifts: 25-Ask for leave, 26-Out, Null-Holiday

Schedule date

2012-1-1

Holiday

Shifts

Leave

On business

Note: Dates must be set correctly. For example, if the scheduling date is 2012-1-1, the schedule setting report contains the schedules of 31 days after 2012-1-1, that is, the schedule from 2012-1-1 to 2012-1-31. If the scheduling date is 2012-1-6, the schedule setting report contains schedules of 31 days after 2012-1-6, that is, the schedule from 2012-1-6 to 2012-2-5.

Step 5: Insert a USB flash drive into the USB port or SD card into the SD port of the device and upload the Attendance Setting Report.xls to the device. Then, the schedules in the Attendance Setting Report can be used.

6. What is the correct time format used in the setting reports?

A. The correct time format is shown in the following table.

Shift No.	First Time Range		Second Time Range		Overtime Range	
	On-duty	Off-duty	On-duty	Off-duty	Check-in	Check-out
1	09:00	18:00				
2	09:00	12:00	13:30	18:00		
3	9:5	18:00				

B. Incorrect time formats are as follows:

- A time value is beyond the time range, such as 24:00.
- A time value contains Chinese characters, for example, 9:00, which differs from 9:00.
- A time value is preceded by a space. As shown in the following table, there is a space in front of 09:00 in shift 1.

Shift No.	First Time Range		Second Time Range		Overtime Range	
	On-duty	Off-duty	On-duty	Off-duty	Check-in	Check-out
1	09:00	18:00				
2	09:00	12:00	13:30	18:00		
3	9:5	18:00				


- A time value contains special characters, for example, _9:00 and 09:-1.

The device performs a validity check and error tolerance for other formats.

7. How does the self-service attendance terminal collect the correct attendance time based on the preset shift time?

A: The device collects attendance time based on the following principles:

- Adopt the earliest time for normal attendance and the nearest time for abnormal attendance.
- Adopt the normal attendance time if the normal attendance time and abnormal attendance time coexist.
- Adopt a median in the attendance time range.



B: The following uses four examples to describe the preceding principles.

Example 1: Normal attendance

Attendance Time Range	09:00 — 12:00	13:00 — 18:00	
Attendance time of #1 employee	8:30, 8:35, 11:55, 12:01, 12:50, 18:02, 19:00		
Statistical result based on attendance rules	8:30	12:01	12:50 18:02

Description: The attendance time 8:30 and 8:35 are earlier than the on-duty time 9:00 and they are within the normal attendance time range. Therefore, 8:30 is adopted for the on-duty time 9:00 based on the principle of adopting the earliest time for normal attendance. 18:02 and 19:00 are later than the off-duty time 18:00, and therefore, 18:02 is adopted based on the same principle.

Example 2: Late arrival

Attendance Time Range	09:00 — 12:00	13:00 — 18:00	
Attendance time of #1 employee	9:01, 9:04, 12:01, 12:50, 18:00		
Statistical result based on attendance rules	9:01	12:01	12:50 18:00

Description: Employer 1 checks in for work at 9:01 and 9:04 and he/she is late based on the preset on-duty time. Based on the principle of adopting the nearest time for abnormal attendance, the correct check-in time is 9:01 rather than 9:04 because of 9:01 is nearer 9:00.

Example 3: Early leave

Attendance Time Range	09:00 — 12:00	13:00 — 18:00	
Attendance time of #1 employee	8:50, 11:40, 11:55, 12:50, 18:01		
Statistical result based on attendance rules	8:50	11:55	12:50 18:01

Description: The attendance time 12:50 is adopted based on the principle of adopting a median in the attendance time range. For the attendance time range from 9:00 to 12:00, the normal check-out time range for the off-duty time 12:00 is from 12:00 to 12:30 (that is, $12:00 + (13:00 - 12:00)/2$). Therefore, the calculated time of attendance is shown in the preceding table.

Example 4: Absence

Case 1:

Attendance Time Range	09:00 — 12:00	13:00 — 18:00		
Attendance time of #1 employee	8:50, 12:50, 18:01			
Statistical result based on attendance rules	8:50		12:50	18:01

Description: The attendance time 12:50 is adopted based on the principle of adopting a median in the attendance time range. For the attendance time range from 9:00 to 12:00, the normal check-out time range for the off-duty time 12:00 is from 12:00 to 12:30 (that is, $12:00 + (13:00 - 12:00)/2$). Therefore, the check-out time is blank. The normal check-in time range for the on-duty time from 13:00 is from 12:30 to 13:00. The calculated time of attendance is shown in the preceding table.

Case 2:

Attendance Time Range	09:00 — 12:00	13:00 — 18:00		
Attendance time of #1 employee	8:50, 11:55, 12:20, 18:01			
Statistical result based on attendance rules	8:50	12:20		18:01

Description: The time 12:20 is adopted based on the principle of adopting a median in the attendance time range. The normal check-out time range for the off-duty time 12:00 is from 12:00 to 12:30 (that is, $12:00 + (13:00 - 12:00)/2$). Therefore, the check-out time of the employee is 12:20. The normal check-in time range for the on-duty time from 13:00 is from 12:30 to 13:00. Therefore, the check-in time of the employee is blank. The calculated time of attendance is shown in the preceding table.

Requirements of Live Collection and Registration of Visible Light Face Images

- 1) It is recommended to perform registration in an indoor environment with an appropriate light source without underexposure or overexposure on the face.
- 2) Do not place the device towards outdoor light sources like door or window or other harsh light sources.
- 3) Dark-color apparels other than the background color is recommended for registration.
- 4) Expose your face and forehead properly and do not cover your face and eyebrows with your hair.
- 5) It is recommended to show a normal facial expression. (A smile is acceptable, but do not close your eyes, or incline your head to any orientation).
- 6) Two images are required for a person with eyeglasses, one image with eyeglasses and the other without them.
- 7) Do not wear accessories like a scarf or mask that may cover your mouth or chin.
- 8) Please face right towards the capturing device and locate your face in the image capturing area as shown in the image below.
- 9) Do not include more than one face in the capturing area.
- 10) A distance of 50cm to 80cm is recommended for capturing the image (the distance is adjustable, subject to body height).




Image1 Face Capture Area

Requirements for Visible Light Digital Face Image Data

The digital photo should be straight-edged, colored, half-portrayed with only one person, and the person should be uncharted and in casuals. Persons who wear eyeglasses should remain to put on eyeglasses for getting photo captured.

- **Eye Distance**

200 pixels or above are recommended with no less than 115 pixels of distance.

- **Facial Expression**

A neutral face or smile with eyes naturally open are recommended.

- **Gesture and Angel**

The horizontal rotating angle should not exceed $\pm 10^\circ$, elevation should not exceed $\pm 10^\circ$, and depression angle should not exceed $\pm 10^\circ$.

- **Accessories**

Masks or coloured eyeglasses are not allowed. The frame of the eyeglasses should not cover the eyes and should not reflect light. For persons with thick eyeglasses frames, it is recommended to capture two images, one with eyeglasses and the other one without them.

- **Face**

Complete face with clear contour, real scale, evenly distributed light, and no shadow.

- **Image Format**

Should be in BMP, JPG or JPEG.

- **Data Requirement**

Should comply with the following requirements:

- 1) White background with dark-colored apparel.
- 2) 24bit true color mode.
- 3) JPG format compressed image with not more than 20kb size.
- 4) Resolution should be between 441 x 358 to 1920 x 1080.
- 5) The vertical scale of head and body should be in a ratio of 2:1.
- 6) The photo should include the captured person's shoulders at the same horizontal level.
- 7) The captured person's eyes should be open and with a clearly seen iris.
- 8) A neutral face or smile is preferred, showing teeth is not preferred.
- 9) The captured person should be easily visible, natural in color, no harsh shadow or light spot or reflection in the face or background. The contrast and lightness level should be appropriate.

Appendix 2

Privacy Policy

Notice:

To help you better use the products and services of ZKTeco and its affiliates, hereinafter referred as "we", "our", or "us", the smart service provider, we consistently collect your personal information. Since we understand the importance of your personal information, we took your privacy sincerely and we have formulated this privacy policy to protect your personal information. We have listed the privacy policies below to precisely understand the data and privacy protection measures related to our smart products and services.

Before using our products and services, please read carefully and understand all the rules and provisions of this Privacy Policy. If you do not agree to the relevant agreement or any of its terms, you must stop using our products and services.

I. Collected Information

To ensure the normal product operation and help the service improvement, we will collect the information voluntarily provided by you or provided as authorized by you during registration and use or generated as a result of your use of services.

1. **User Registration Information:** At your first registration, the feature template (**Fingerprint template/Face template/Palm template**) will be saved on the device according to the device type you have selected to verify the unique similarity between you and the User ID you have registered. You can optionally enter your Name and Code. The above information is necessary for you to use our products. If you do not provide such information, you cannot use some features of the product regularly.
2. **Product information:** According to the product model and your granted permission when you install and use our services, the related information of the product on which our services are used will be collected when the product is connected to the software, including the Product Model, Firmware Version Number, Product Serial Number, and Product Capacity Information. **When you connect your product to the software, please carefully read the privacy policy for the specific software.**

II. Product Security and Management

1. When you use our products for the first time, you shall set the Administrator privilege before performing specific operations. Otherwise, you will be frequently reminded to set the Administrator privilege when you enter the main menu interface. **If you still do not set the Administrator privilege after receiving the system prompt, you should be aware of the possible security risk (for example, the data may be manually modified).**

2. All the functions of displaying the biometric information are disabled in our products by default. You can choose Menu > System Settings to set whether to display the biometric information. If you enable these functions, we assume that you are aware of the personal privacy security risks specified in the privacy policy.
3. Only your user ID is displayed by default. You can set whether to display other user verification information (such as Name, Department, Photo, etc.) under the Administrator privilege. **If you choose to display such information, we assume that you are aware of the potential security risks (for example, your photo will be displayed on the device interface).**
4. The camera function is disabled in our products by default. If you want to enable this function to take pictures of yourself for attendance recording or take pictures of strangers for access control, the product will enable the prompt tone of the camera. **Once you enable this function, we assume that you are aware of the potential security risks.**
5. All the data collected by our products is encrypted using the AES 256 algorithm. All the data uploaded by the Administrator to our products are automatically encrypted using the AES 256 algorithm and stored securely. If the Administrator downloads data from our products, we assume that you need to process the data and you have known the potential security risk. In such a case, you shall take the responsibility for storing the data. You shall know that some data cannot be downloaded for sake of data security.
6. All the personal information in our products can be queried, modified, or deleted. If you no longer use our products, please clear your personal data.

III. How we handle personal information of minors

Our products, website and services are mainly designed for adults. Without consent of parents or guardians, minors shall not create their own account. If you are a minor, it is recommended that you ask your parents or guardian to read this Policy carefully, and only use our services or information provided by us with consent of your parents or guardian.

We will only use or disclose personal information of minors collected with their parents' or guardians' consent if and to the extent that such use or disclosure is permitted by law or we have obtained their parents' or guardians' explicit consent, and such use or disclosure is for the purpose of protecting minors.

Upon noticing that we have collected personal information of minors without the prior consent from verifiable parents, we will delete such information as soon as possible.

IV. Others

You can visit https://www.zkteco.com/cn/index/Index/privacy_protection.html to learn more about how we collect, use, and securely store your personal information. To keep pace with the rapid development of technology, adjustment of business operations, and to cope with customer needs, we will constantly deliberate and optimize our privacy protection measures and policies. Welcome to visit our official website at any time to learn our latest privacy policy.



Eco-friendly Operation



The product's "eco-friendly operational period" refers to the time during which this product will not discharge any toxic or hazardous substances when used in accordance with the prerequisites in this manual.

The eco-friendly operational period specified for this product does not include batteries or other components that are easily worn down and must be periodically replaced. The battery's eco-friendly operational period is 5 years.

Hazardous or Toxic substances and their quantities

Component Name	Hazardous/Toxic Substance/Element					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr6+)	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Chip Resistor	×	○	○	○	○	○
Chip Capacitor	×	○	○	○	○	○
Chip Inductor	×	○	○	○	○	○
Diode	×	○	○	○	○	○
ESD component	×	○	○	○	○	○
Buzzer	×	○	○	○	○	○
Adapter	×	○	○	○	○	○
Screws	○	○	○	×	○	○

○ indicates that the total amount of toxic content in all the homogeneous materials is below the limit as specified in SJ/T 11363—2006.

× indicates that the total amount of toxic content in all the homogeneous materials exceeds the limit as specified in SJ/T 11363—2006.

Note: 80% of this product's components are manufactured using non-toxic and eco-friendly materials. The components which contain toxins or harmful elements are included due to the current economic or technical limitations which prevent their replacement with non-toxic materials or elements.

ZKTeco Industrial Park, No. 32, Industrial Road,

Tangxia Town, Dongguan, China.

Phone : +86 769 - 82109991

Fax : +86 755 - 89602394

www.zkteco.com

