


3 Feet Water Bubble Tube User Guide

This guide has been written to help you get the most from your bubble tube. Please ensure that you read this fully as it contains important information on filling, emptying and maintaining your tube. Failure to follow this advice may result in damage to the tube and invalidate your warranty.

nozig
we are inclusive

Congratulations on the purchase of your Sensory Bubble Tube!

Calm yourself as you watch the fishes and colors change and feel the gentle vibration of the Calming LED Bubble Tube. Watching the bubbles and fishes rise helps those who are overstimulated to calm and those who are under-stimulated to respond.
Attach the bubble tube to the wall with the bubble tube wall bracket for added stability and safety.

Item: 3 Feet Water Bubble Tube
SKU: BT100C

Your package should have:














1) a 3 feet acrylic bubble tube
2) a adapter
3) remote controller
4) pack of plastic cover, 2 screws and 2 wall plugs
5) a pack of acrylic translucent balls
6) a stainless steel bracket

Here are steps on how to assemble your new bubble tube:

1) Place the bubble tube near a wall
2) Remove the outer plastic wrapper
3) Slide in the bracket to the bubble tube
4) Drill the bracket to the wall
5) Fill the tube with water and place in the acrylic translucent balls
6) Turn on the power, enjoy
7) To change the color of the tube, use the remote controller





Berikut adalah langkah cara memasang tiub baharu anda:

1) Letakkan tiub di sudut berhampiran dinding
2) Tanggalkan pembungkus plastik luar
3) Sarungkan braket ke tiub (Seperti dalam gambar)
4) Gerudi braket ke dinding
5) Isikan air dalam tiub, dan kemudiannya isikan bebola
6) Pasangkan elektrik
7) Untuk menukar warna tiub, gunakan alat kawalan jauh (yang disertakan)



Maintenance Guidance

1. Water Replacement

It is recommended to replace the water inside the bubble tube every 4-6 weeks to ensure cleanliness and optimal performance.

2. Algaecide Use

Add a small amount of the provided algaecide each time you refill or replace the water. This helps prevent algae buildup and keeps the water clear.

3. Cleaning the Tube

If there is visible dirt or buildup, carefully empty the water and clean the inner surface of the bubble tube using a soft brush or sponge. Do not use harsh chemicals or abrasive tools.

4. Checking Connections

Periodically inspect all power cables, air tubing, and light engine connections to ensure they are secure and functioning properly.

6. Air Pump Care

Keep the air pump in a dry and ventilated space inside the base. Do not block air vents to ensure quiet and efficient operation.

7. Storage

If the unit will not be used for an extended period, drain all water, unplug all power sources, and store in a cool, dry place.

nozig
we are inclusive

Troubleshooting

1. Bubble Tube Not Producing Bubbles

Check if the air pump is plugged in and switched on.
Ensure the air tubing is properly connected to both the pump and the bubble tube.
Inspect for any kinks or blockages in the tubing.
Make sure the water level is sufficient.

2. Lights Not Turning On

Verify that the power adapter is securely connected to the fiber optic light engine.
Check if the power source is active and working.
Ensure the remote or controller (if used) has battery power and is correctly paired.

3. Water Appears Cloudy or Green

Add a small amount of algaecide if not already used.
Consider replacing the water if it's been in the tube for more than 4-6 weeks.
Clean the interior of the bubble tube gently if needed.

4. Unusual Noise from Air Pump

Confirm the pump is placed on a stable and flat surface inside the base.
Ensure the air vents are not blocked.
Check for debris inside the pump or tubing.

Emptying water for maintainance and storage

We have provided a manual water pump to aid in emptying your Bubble Tube. Attach the hose to the nozzle closer to the handle on the manual pump and place the other end of the hose deep into the panel. Place a large bucket on the floor (or at a lower point than the end of the hose) and start pumping until the water starts flowing. (Scan the QR below for instructions)

IMPORTANT:
DO NOT USE any wipes or sprays that contain **ALCOHOL, AMMONIA, or BLEACH** on the Bubble Tubes.These ingredients will deteriorate the acrylic and result in spider cracks which will cause leaks in the Bubble Tube. Use non alchohol wipes or wet clothes on the outside of Bubble Tubes.

Warranty

All products manufactured by ourselves are backed with a one year guarantee from the date of purchase.
All other items carry a manufacturers 1 year guarantee.
If your product needs to be returned to our factory we will arrange collection of the item and return it to you when repaired, all we ask is you pack the product securely.
If in the unlikely event that a product purchased from us develops a fault please contact us at **016-9763128** or email us at **info@nozig.com.my** and our technical team will assist.

Nozig Registered Office:
Block D1, 39, Jalan PJU 1/41, Dataran Prima, 47301 Petaling Jaya, 47301, Petaling Jaya, Selangor, Malaysia.

If you have any questions or need information about any of our products and services please call us on 016-9763128

nozig
we are inclusive
Ask us more!

nozig
we are inclusive
www.nozig.com.my

0169763128
info@nozig.com.my