

Sensory Fiber Optic Carpet User Guide

This guide has been written to help you get the most from your Fiber Optic Mat. Please ensure that you read this fully as it contains important information. Failure to follow this advice may result in damage to the Fiber Optic and invalidate your warranty.

nozig
we are inclusive

Sensory Fiber Optic Carpet



Fiber optic carpet consists of tiny fiber optic lights woven into black carpet to create a pattern of lights. They are safe for any user, as fiber optic strands are very thin and do not carry any electrical current or heat up with use.

Includes:
Includes light source.

Size: 1m x 1m

Contents:
1 x Carpet
1 x USB cable
1 x Non replaceable rechargeable 3.7 Polymer Lithium Li-ion Battery



Instructions for use:
Unroll the carpet and place on the floor in a safe location. Press the button located on the charging cable to activate the carpet. Flashing lights indicate the unit is on, touch to activate. The carpet will change through a sequence of colors and stay lit for 60 seconds. If the button is pressed a second time, the light will turn off. Tread firmly on the carpet for it to stay lit. If the carpet no longer illuminates, connect the charger as described in the battery information section.

How To clean:
To clean wipe with a soft damp cloth. Do not immerse in water or wash in the washing machine. The carpet can be vacuumed.

Please note: Only use the cable supplied. Use of a different cable may result in damage to the product and void the warranty.

Fiber Optic Safety
*** Make sure that the carpet is flat and secure before allowing anyone to walk over it.**
*** If the carpet has been stored in a rolled up state, then the carpet will not lay flat for some time.**
*** Wheelchairs, pushchairs or strollers should not be rolled over the carpet.**
*** Please secure the fiber optic 'tail' (which is connected to the lightsource) before use or this may be a tripping hazard.**

*Please follow all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is de-fective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product. Warranty: 1year**

nozig
we are inclusive