

realme


BLUETOOTH SOUNDBAR WITH WIRED SUBWOOFER



MODEL: RMV2002

**PLEASE READ THIS MANUAL CAREFULLY BEFORE OPERATION
AND KEEP IT FOR FUTURE REFERENCE**

IMPORTANT SAFETY INSTRUCTIONS



CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). NO USER SERVICEABLE PART INSIDE, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



DANGEROUS VOLTAGE: The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



ATTENTION: The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

WARNING: USE UNDER SUPERVISION OF AN ADULT DUE TO LONG CORD

This unit has a long cord that can be easily tripped on or pulled on, causing injury. Please make sure it is arranged so that it will not drape over a tabletop, etc. Where it can be pulled on by children or tripped over accidentally.

IMPORTANT SAFETY INSTRUCTIONS

Before using the unit, be sure to read all operating instructions carefully, please note that these are general precautions. Some of the following may not pertain to this unit.

1. Read these instructions

All the safety and operating instructions should be read before the appliance is operated.

2. Keep these instructions

The safety and operating instructions should be kept for future reference.

3. Heed all warnings

All warnings on the appliance and in the operating instructions should be adhered to.

4. Follow all instructions

All operation and use instructions should be followed.

5. Do not use this apparatus near water

The appliance should not be used near water; for example, near a bath tub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.

6. Clean only with dry cloth

The appliance should be cleaned only as recommended by the manufacturer.

7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Slots and openings in the cabinet and in the back or bottom are provided for ventilation, to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or similar surface. This product should never be placed near or over a radiator or heat source. This product should not be placed in a built-in installation, such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

9. Do not defeat the safety purpose of the grounding-type plug. A grounding type plug has two prongs and a third grounding prong. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

11. Only use attachments / accessories specified by the manufacturer.

12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus.

When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



Portable Cart Warning

An appliance and cart combination should be moved with care. Quick stop, excessive force and uneven surfaces may cause the appliance and cart combination to overturn.

13. Unplug this apparatus during lightning storms or when unused for long periods of time.

To protect your product from a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet. This will prevent damage to the product due to lightning and power-line surges.

14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, do not operate normally, or has been dropped.

15. Power source

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For products intended to operate from battery power, or other source, refer to the operation instructions.

16. Power lines

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

17. Overloading

Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

18. Object and liquid entry

Never push objects of any kind into the product through openings as they may touch dangerous voltage points or short out parts that could result in fire or electric shock. Never spill or spray any type of liquid on the product.

19. Service

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

20. Replacement parts

When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics as the original parts. Unauthorized substitutions may result in fire or electric shock or other hazards.

21. Safety check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

22. Wall or ceiling mounting

The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

23. Damage requiring service

Unplug this product from the wall outlet and refer service to qualified service personnel under the following conditions.

- a) When the power-supply cord or plug is damaged.
- b) If liquid has been spilled or objects have fallen into the product.
- c) If the product has been exposed to rain or water.
- d) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an adjustment of other controls may result in damage and will require extensive work by a qualified technician to restore the product to its normal operation.
- e) If the product has been dropped or the cabinet has been damaged.
- f) When the product exhibits a distinct change in performance- this indicates a need for service.

PACKAGE CONTAINS



1. realme soundbar




2. User Manual




3. Subwoofer



4. Remote Control



5. Power adapter




6. 2xMetal Bracket



7. 4xScrews



8. 4xPlastic plugs



9. 2xBatteries




10. HDMI cable




11. Coaxial cable

MOUNTING

1. Mounting Distance




2. Mounting to the wooden wall



- A. Mark the position of the mounting screws on the wall.
- B. Drill the screws directly into the marks you have made on the wall and leave 0.25 inches length to hook the soundbar.
- C. Put the sound bar onto the mounting screws, make it firm and stable.


3. Mounting to the brick wall




- A. Mark the position of the mounting screws on the wall.
- B. Drill 2 holes on wall with a powerful electric drill.
- C. Insert the fixing plugs and hammer into the holes.
- D. Secure the screws into the fixing plugs and leave 0.25 inches length to hook the soundbar.
- E. Put the sound bar onto the mounting screws, make it firm and stable.

PRODUCT OVERVIEW

TOP PANEL




REAR PANEL



1. Mode button: press repeatedly to switch to bluetooth, ARC, USB, optical, AUX in or coaxial mode.
2. Play/Pause button: press to play or pause.
3. Power on/off button: press to power on or off.
4. Volume down button: press and hold to decrease the volume level, press to skip to previous track.
5. Volume up button: press and hold to increase the volume level, press to skip to next track.
6. Optical in jack
7. Coaxial jack
8. ARC in jack
9. Subwoofer out jack
10. AUX in jack
11. USB slot
12. DC IN jack


FRONT VIEW



13. Remote sensor: for remote control
14. LED indicator 1: bluetooth mode, blinks blue for pairing, stay blue when connected successfully.
15. LED indicator 2: ARC mode, light blue
16. LED indicator 3: blinking green for indicating volume level, it will turn red while the unit enters standby mode.
17. LED indicator 4: optical mode, light blue
18. LED indicator 5: AUX in mode, light blue


NOTE: when LED 1 and LED 2 light blue, it indicates USB mode.
when LED 4 and LED 5 light blue, it indicates coaxial mode.

SUBWOOFER



19. Speaker
20. Cable plug: insert to the SUB jack on the rear panel for amplification.


REMOTE CONTROL



1. Power on/off button
2. Bluetooth mode button
3. Previous button
4. Play/pause button
5. EQ mode(MOVIE, MUSIC, NEWS) button
6. Aux/Arc mode button
7. Optical/Coaxial mode button

8. Mute mode button
9. Volume up button
10. Next button
11. Volume down button
12. USB mode button


The remote control sensor at the front of the soundbar is sensitive to the remote control's commands up to a maximum of 7 metres away and within a maximum arc of 30 degrees. Please note that the operating distance may vary depending on the brightness of the room.



POWER SUPPLY

NOTE: The AC input of the adapter is 100~240V, 50/60Hz, the output is 20V, 2.5A.

1. Insert the plug into the other part as shown in step 1.
2. Insert the DC plug to the DC IN jack on the rear of the unit.
3. Insert the AC plug into the AC outlet.



BLUETOOTH OPERATION

1. Pairing a Bluetooth Device for the first time.
2. Press the POWER button on the unit or the remote control to switch on the unit.
3. Press the BT button on the remote control or press the M button on the unit repeatedly until the LED 1 blinking blue to switch to bluetooth mode.
4. Using the native controls on your Bluetooth device, select the "realme soundbar" in your Bluetooth settings to pair and try to connect.
5. When successfully paired and connected, a beep will issue from the unit. After initial pairing, the unit will stay paired unless unpaired manually.
6. If your device should become unpaired or it is unable to connect, repeat the above steps. After successful paired, the LED 1 indicator will be solid blue.
7. During playing:
Press the |< or >| button on remote control to skip tracks.
Or press the - or + button on the unit to skip tracks.
Press the >|| button on remote control to pause, press it again to resume.
Or Press the ▶|| button on the unit to pause, press it again to resume.
8. If you want to disconnect the current connection, press and hold the ▶|| button on the unit or press and hold the BT button on remote control for about 2 seconds to disconnect.


Note:

The unit will be automatically connected with the last connected Bluetooth device if their Bluetooth function are activated and they are in working range.

HDMI(ARC) IN OPERATION

1. You will need: An audio source with an ARC Audio Output and a ARC Audio cable (not included).
2. Connect the ARC Audio cable to the ARC output on the audio source and to the ARC Input on the soundbar.
3. Press the POWER button on the unit or the remote control to switch on the unit.
4. Press the AUX/ARC button twice on the remote control or press the M button on unit repeatedly until the LED 2 lighting blue to switch to ARC mode.
5. Using the native controls on your connected device, make sure the audio settings are set to ARC or HDMI Audio and are turned on. Audio from the connected audio source will now be played through the speakers.


NOTE: Set the digital output mode to PCM mode only on TV.



REAR PANEL

OPTICAL IN OPERATION

1. Connect the OPTICAL OUT jack from the external audio player (such as TV, DVD player etc.) to the OPT jack on the rear of the unit.
Connection is illustrated below:(For PCM format only)




2. Press the POWER button on the unit or the remote control to switch on the unit.
3. Press the OPT/COAX button on the remote control or press the M button on the unit repeatedly until the LED 4 lighting blue to switch to optical mode.

NOTE:
Press the OPT/COAX button on the remote control ONCE to switch to OPT function. Press this button TWICE to switch to COAX function.
Press this button repeatedly to switch to OPT or COAX.

4. Using the native controls on your connected device, make sure the audio settings are set to PCM or Optical Audio and are turned On. Audio from the connected audio source will now be played through the speakers.

AUX IN OPERATION


1. This unit can be connected to the TV and listen through the speakers.
2. Plug one end of the AUX IN cable into the AUX jack on the unit.
3. Plug another end of the AUX IN cable into the L&R jacks on the TV.



4. Press the AUX/ARC button once on the remote control or press the M button on the unit repeatedly until the LED 5 lighting blue to switch to AUX IN mode.
5. Power on the connected TV and start playing.

USB OPERATION

1. Press the USB button on the remote control or press the M button on the unit repeatedly until the LED 1 and 2 lighting blue to switch to USB mode.
2. Insert USB player to play music automatically.



3. During playing:

Press the |< or >| button on remote control to skip tracks.

Or press the - or + button on the unit to skip tracks.


Press the >|| button on remote control to pause, press it again to resume.

Or Press the ▶|| button on the unit to pause, press it again to resume.

4. Audio played through the connected USB device will now be heard through the speakers.

COAXIAL OPERATION

1. Connect the COAXIAL OUT jack from the external audio player (such as TV, DVD player etc.) to the COAX jack on the rear of the unit.
2. Connect the Digital Coaxial Audio cable to the optical output on the audio source and to the Coaxial Input on the soundbar.
Connection is illustrated below:(For PCM format only)



3. Press the POWER button on the unit or the remote control to switch on the unit.
4. Press the OPT/COAX button on the remote control twice or press the M button on the unit repeatedly until the LED 4 and 5 lighting blue to switch to coaxial mode.

NOTE:

Press the OPT/COAX button on the remote control ONCE to switch to OPT function. Press this button TWICE to switch to COAX function.
Press this button repeatedly to switch to OPT or COAX mode.

5. Using the native controls on your connected device, make sure the audio settings are set to PCM or Coaxial Audio and are turned On. Audio from the connected audio source will now be played through the speakers.

TROUBLESHOOTING

If the unit does not work properly as desired, please check the following.

Malfunction	Possible causes/measures
No power / function	1. Check whether the power is switched on or off at the wall. 2. Check whether the power adaptor is properly connected to power outlet or not. 3. Press the POWER button on the unit or remote control to power on
No sound	1. Check whether cables are properly installed. If they are, please try alternative cable to connect to your TV if possible. 2. Check unit is out of standby and in mode. 3. Raise the volume level by pressing the + Button on the unit 4. Play music/movie in the paired/connected device and make sure volume level is high
No sound from Bluetooth connection	1. Disconnect the unit from your device and reconnect. 2. The external device is too far from the unit. Put the external BT device close to the unit.
Function disturbance	1. Switch off and unplug the unit. Leave it for 2 minutes and switch it on again. 2. If a particular mode is causing problems, please try an alternative connection to your TV such as Optical or Bluetooth. 3. Out of range : Point the remote control to the remote sensor on the unit within 23 feet, +/-30 degree.
Remote control does not work [properly]	1. Check whether the battery run out or not. Replace with a new one if necessary. 2. Check whether there is obstacle on the front of remote sensor.

SPECIFICATIONS

Power Supply:	INPUT:100~240V~50/60Hz 1.2A OUTPUT:DC 20V,2.5A.
Speaker Output Power	100W (Soundbar 60W+ Subwoofer 40W)
Speaker Size & Number	2.0" Full range speaker x 2 + 2.0" Tweeter speaker x 2
Speaker Size(Wireless):	5.25" Subwoofer*1
Working environment (Temperature)	-10~ + 50 °C
Relative Humidity	35% ~ 85%
Frequency Response	20Hz -23KHz
Bluetooth Version	V5.0
Bluetooth Distance	10M
Dimension (LxWxH)	940mm x93mm x70mm (Soundbar)
Dimension (LxWxH)	250mm x110mm x 350mm (Wired Subwoofer)
Operating frequency	2.4GHz
Number of channels	79 channels

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE
WITHOUT NOTICE.

Warranty

Thank you for purchasing realme products. If any manufacturing defect problems occur within 12 months from the date of purchase, user can enjoy our company's warranty service.

Matters Needing Attention:

1. When you buy the product, the sales unit will issue a valid proof of purchase.
2. The warranty card and the proof of purchase should be kept by the user properly, and it will not be replaced if lost.
3. If the product fails due to non-human factors, the user can present the warranty card and proof of purchase to the realme customer service center for free maintenance during the warranty period.

Non-warranty situation:

This warranty does not cover the following cases:

1. Out of warranty period.
2. Damage caused by use not in accordance with the instructions.
3. Damage caused by man-made causes.
4. Failure caused by unauthorized disassembly, maintenance, or modification of the product.
5. Damage caused by force majeure factors (such as floods, earthquakes, lightning, etc.).
6. There is no warranty card, invoice, or warranty card that does not match the invoice information.
7. The product wears naturally.
8. Other failures and damages that are not caused by the quality of the product itself.

Website : www.realme.com

Email: service@realme.com

Hotline: 1800-102-2777

Warranty Card (Stub Copy)

Dear user, thank you for using the product of our company.

Please read and keep properly the warranty card after purchasing the product so that we can provide better services to you.

User Information

User's name _____
Phone Number _____
Address _____
Email _____

Product Information

Product Model _____
Product Serial Number _____

Sales Information

Purchase Date _____
Invoice Number _____
Sales Unit _____
Phone Number _____
Address _____

Warranty Card (Customer Copy)

Dear user, thank you for using the product of our company.

Please read and keep properly the warranty card after purchasing the product so that we can provide better services to you.

User Information

User's name _____
Phone Number _____
Address _____
Email _____

Product Information

Product Model _____
Product Serial Number _____

Sales Information

Purchase Date _____
Invoice Number _____
Sales Unit _____
Phone Number _____
Address _____

Recycling Initiative (India)

At realme we understand that our responsibility doesn't end at selling you our products. realme has been working in the area of safe disposal of electronic waste. Since mobiles, tablets and other electronic items are made of hazardous constituents. Under the Guidelines of Ministry of Environment, Forest and Climate Change, Government of India, E-waste (Management) Rule, 2016 and Amendment E-waste Rule 2018.

realme will seek shared responsibility and cooperation from customers in reducing the environmental impact of their products. realme will comply with all the applicable laws related to E-waste management.



For more information on safe disposal, recycling and you may log on to <https://www.realme.com/in/legal/e-waste-management> or write an email to service@realme.com or contact our Toll Free No. 1800-102-2777

Disposal and Recycling Information

This symbol (with or without a solid bar) on the device, batteries (included), and / or the packaging, indicates that the device and its electrical accessories (for example, a headset, adapter or cable) and batteries should not be disposed of as household garbage.

