



E-Tenant App


User Guide



E-Tenant App User Guide

First-time use E-Tenant

Step 1 : Download E-Tenant



- Scan the QR Code below to download E-Tenant App
- Search “E-Tenant” on Google Play or App Store



IOS




Android


Step 2 : Select language



Select language



English/Chinese(Traditional)



Next


Step 3 : Enter ID





First-time open E-Tenant App

1. Enter ID or press  to scan the QR code of the ID which offered by administrator
2. Accept DAE Terms of Service and privacy statement
3. Press “Next”



Step 4 : Register



Register



Email is your account





Enter the PIN



Step 5 : Login, pair meter



Login




Meter unpaired





Go to Setting



Step 5 : Login, pair meter



Press "Meter info"




**Scan the QR Code offered by administrator,
or press "ENTER METER NO."**





**Enter the meter No.
or your room No.**

Step 5 : Login, pair meter



Meter is paired



Go to "Info" for your room info



E-Tenant App User Guide






E-Tenant App User Guide

Login



1. Enter your E-mail and password to login
2. Use “FORGOT P/W” to reset your password
3. Mark this check box to keep log-in

Menu




Room info

Top up and history

System message


Settings

Room info



Electricity usage info

How to top up



E-Tenant App



Low Credits
(App message)



Go to
Kiosk



How to top up


Step 1. Scan QR Code



Step 2. Selections




Step 3. Pay to Top Up




Open E-Tenant
Go to "Top up"



Top-up history



Go to "Top-up history"



Click on any history
(in 90 days)



Show details


Message



System message within 90 days


1. Low Credits
2. Top-up Notification
3. Top-up Failed
4. Meter Status Changed
5. Meter disconnected

Setting



1. User info : Change username, password
and delete account
2. Meter info : Pair/unpair meter
3. Language : English/Chinese (Traditional)
4. App version
5. Log out


Setting




User info



Language



Unpair



Log out

Thank you !